

ASEDrive IIIe CL – ISO 14443 A/B reader/writer

Installation Instructions

Installing your ASEDrive IIIe is an easy procedure. Please follow the instructions below:

1. Download and save on your PC the latest driver installation utility from: <http://www.asedrive.com/downloads>
2. Make sure that the ASEDrive IIIe reader is not connected to your PC.
3. Run the installation utility.
4. Follow instructions on the screen.
5. Your ASEDrive is ready for use.

If you encounter any problem during installation or operation of your ASEDrive IIIe, please contact the ASE Technical Support Team at: techsup@athena-scs.com.

FCC Compliance



FCC ID: WQCASE031

This device uses, generates, and radiates radio frequency energy. The radio frequency energy produced by this device is well below the maximum exposure allowed by the Federal Communications Commission (FCC).

Operation is subject to the following conditions:

- This device may not cause harmful interference.
- This device must accept any interference received, including interference that may cause undesired operation.

The ASEDrive IIIe CL has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is located.
- Consult the dealer or an experienced radio/TV technician.

FCC Warning

Modifications not expressly approved by the manufacturer could void the user authority to operate the equipment under FCC rules.

Compliance with FCC regulations:

In order to ensure compliance with FCC regulations, use only the shielded USB cable delivered with this product.

EC Declaration of Conformity



We K.K. Athena Smartcard Solutions of
1-14-16, Motoyokoyama-cho
Hachioji-shi, Tokyo, 192-0063
JAPAN

Declare that the ASEDrive IIIe CL contactless ISO14443 A/B smart card reader is in conformity with the following European Directives:

1999/5/EG – Radio Directive
89/336/EEG – EMC
73/23/EEC – Low Voltage Directive

Conformity to the above directives is assured through application of the following standards:

EN 55022: 2006
EN 55024: 1998+A1:2001+A2:2003
IEC 61000-4-2: 2001 ED.1.2
IEC 61000-4-3: 2006 ED.3.0
IEC 61000-4-8: 2001 ED.1.1
EN 300 330
EN 301 489-1/-3
EN60950-1 (2001)



Eran Navoth
Director

Instructions for Disposal of Waste Equipment by Users in Private Households



This symbol on the product or on its packaging indicates that this product must not be disposed of with your other household waste. Inappropriate disposal may be harmful. Instead, it is your responsibility to dispose of your waste equipment by handing it over to a designated collection point for the recycling of waste electrical and electronic equipment. The separate collection and recycling of your waste equipment at the time of disposal will help to conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment. For more information about where you can drop off your waste equipment for recycling, please contact your local city office, your household waste disposal service or the shop where you purchased the product.

Additional Standard Compliance

CISPR 22: 2006 ED5.2

Contact us: sales@athena-scs.com

<http://www.athena-scs.com>