




RBW 3 MHz Marker 1 [T1]
 VBW 10 MHz -5.73 dBm
 SWT 100 ms 17.400000 ms

Ref 13 dBm

Att 50 dB

1 AP
 VIEW






RBW 3 MHz
VBW 10 MHz
SWT 20 ms

Ref 13 dBm

Att 50 dB

1 AP
VIEW



A

Duty Cycle
= $(0.4 + 2.12) / 100$
= $2.52 / 100$
= 0.0252

Average Factor
= $20 \log 0.0252$
= -32.0dB

3I

Center 2.409853 GHz

2 ms/