





# Troubleshooting

Battery	250 mAh LiPo Battery
Bluetooth	V3.0 A2DP
Bluetooth range	10 m
Frequency response	2.402 GHz - 2.480 GHz
Play time	up to 9 hours
Charging time	up to 2 hours
Dimensions	H45 x W43.8 x D13.1 (mm)
Weight	20 g

Specifications:

We hope you've now got all the information you need to get started, but if you're having problems with anything, please feel free to contact us at: support@kitsound.co.uk

Please do not attempt to open this product. There are no user serviceable parts riseds on indiction to open in sproduct. There are no seen serviceable battery, do not attempt to access or remove the battery as this may cause personal injury and will damage the product. Making any attempt to open the product or carry out repair voids any and all warranties.

We apologise for any inconvenience caused by minor inconsistencies in these instructions, which may occur as a result of product improvement and development.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

oReorient or relocate the receiving antenna.

ollicrease the separation between the equipment and receiver.

oConnect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

### Please read this manual carefully before use.

# Box contents

- KS Bluetooth Airline Adaptor
- Charge cable User manual
- 3.5MM audio cable

# Functions

We are craftspeople. We are musicians. We are KitSound

Bringing people closer to their music. By truly understanding music we stay true to its craft. Pure, rich, incredible sound.

We'll settle for nothing less.

This device complies with Part 15 of the FCC Rules. Operation is subject to

the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference

that may cause undesired operation.

1. Multi Function Button (MFB) 2. Micro USB charge port 3. Twin 3.5 mm mono jack plugs 4. LED indicator

# Instructions for use

## Charging

- It is recommended that you give the Adaptor a full charge before its first use.
- 1. Plug the micro USB end of the charge cable into the Adaptor micro USB charge port (2)
- 2. Plug the standard USB cable end into either a computer or a USB mains charger
- 3. The LED indicator (4) will be solid red whilst charging 4. When charging is complete, the LED indicator (4) will turn off Note: It may take up to 2 hours before the Adaptor is fully charged. Note: The LED indicator (4) will flash red every 6 seconds when low on battery.

#### Getting started

To turn the Adaptor on, press and hold the MFB (1) for 3 seconds, and to turn it off press and hold for 3 seconds.

### Pairing the Adaptor to your Bluetooth headphones

Before you can use the transmitter via Bluetooth, it will need Simply plug the twin 3.5 mm mono jack plugs (3) into the airline to be paired to your Bluetooth headphones. To do this:

- 1. Hold the MFB (1) for 6 seconds or until the LED indicator (4) starts flashing red and blue, this is to show the Adaptor is in
- 2. Turn your Bluetooth headphones on and put them into pairing mode
- 3. Once both are in pairing mode, hold the two next to each other and let them find each other
- 4. Once connected the LED indicator (4) on the Airline Adaptor will be solid blue

Please note: Please make sure no other Bluetooth headphones are in pairing mode when you try to connect. The Adaptor will automatically connect to the previous Bluetooth headphones when both turned on.

#### Playing inflight entertainment

entertainment socket and you will now be able to listen with your Bluetooth headphones.

#### Care for your KS Airline Adaptor Please DON'T:

Get the Adaptor wet

- Drop the Adaptor as this will invalidate your warranty Open up the Adaptor. There are no user serviceable parts inside
- Expose the Adaptor to extreme temperatures or rapid changes of hot to cold or vice versa

#### Please DO:

Clean the Adaptor with a soft dry cloth and no detergents