


60MM

正面

S030

Ucomx. 优康仕



磁吸充电蓝牙耳机说明书 CH

前言

尊敬的用户：

非常感谢您选用“S030”磁吸充电蓝牙耳机请在
使用前, 仔细阅读本说明书, 正确操作使用, 更好发
挥产品优越性能。我司蓝牙耳机外观设计时尚绚丽、
小巧便携、音质纯美、多功能一体化设计, 全系列拥
有外观设计专利, 系统上采用了行业领先电声技术,
使您在居家使用、户外旅行、商务工作中随时随地享
受到卓越的音响效果, 为您的笔记本电脑、数码音乐
播放器等视听产品提供超值完美的音质, 带您聆听美
妙音乐, 感受健康快乐生活!

大康 蓝牙耳机

注意事项 / 温馨提示

注意事项：


- 请在常温环境中存放以及使用本产品；
- 请勿将本产品暴露在雨中或潮湿环境中；
- 请勿丢弃，避免因跌落造成产品损坏；
- 请勿自行拆解、修理和改造本产品；
- 请勿使用化学溶剂擦拭本产品；
- 如有需要, 请使用输出电压DC5V的USB电源充电器
来充电；
- 请勿随意丢弃, 或置于高温(温度高于60度)与火中,
以免引起危险!

全国统一服务热线：400-881-0138

背面

S030

Ucomx. 优康仕



TWS Bluetooth headset User Manual EN

Precautions / Tips

Cautions

- Please keep or use this product at normal temperature;
- Do not expose this product in rain or moisture;
- Do not throw this product in case any damage thus made;
- Do not disassemble, repair or reform this product;
- Do not clean this product with any chemical solvents;
- Please use USB power of DC5V for output when needed;
- Do not throw away or put it in fire to avoid any danger.



80MM

产品描述

耳机：
产品名称：磁吸充电蓝牙耳机
蓝牙版本：V4.2
充电方式：充电盒
电池指标：高性能锂聚合物锂电池
蓝牙指标：Class 2
支持协议：Headset/Handsfree/A2DP/AVRCP
通话时间：约4小时
播放音乐时间：约4小时
待机时间：约100小时

充电盒：
输入：USB DC5V
输出：充电触点 DC5V

产品示意图





产品描述

Headsets:
Item: TWS Bluetooth headset
Bluetooth standard: V4.2
Charging means: USB DC5V
Battery: High-capability rechargeable lithium polymer battery
Bluetooth Operation: class 2
Profiles Supported: Headset/Handsfree/A2DP/AVRCP
Talking time: About 4 hours
Playing time: About 4 hours
Standby time: About 100 hours

Charging dock:
Input: USB DC5V
Output: Charging contacts DC5V

Product Schematic



功能介绍

- 🔋 开机-在关机状态下, 长按“MFB”键4秒, 绿灯亮; 关机-在开机状态下, 长按“MFB”键3秒, 红灯熄灭;
- 📞 接听电话-来电时单击“MFB”键;
- 📞 挂断电话-通话过程中单击“MFB”键;
- 📞 拒接电话-按手机挂断键或长按“MFB”键约1秒。
- 📞 未码拨号-在耳机处于待机状态下双击“MFB”键针对最后一个拨出的电话号码进行重拨 (注: 须手机支持BLUETOOTH重拨模式)。
- 🎵 音乐播放-在音乐播放状态下短按“MFB”键可进行播放/暂停。
- 🔄 复位功能-充电状态中, 双击“MFB”键, 清除耳机配对信息, 绿灯闪烁。
- 📞 三方通话-通话时, 单击“MFB”键挂断当前电话, 接通等待电话; 双击“MFB”键可在等待电话和当前电话之间切换。
- 🔋 低电报警-开机状态中, 当电池电压低时, 每隔20秒发出一次提示音并闪红灯。

功能介绍

- 🔋 低电关机-开机状态中, 当电池电压过低时, 耳机将自动关机。
- 🔋 充电
耳机充电: 耳机放入充电盒亮红灯, 充满电亮绿灯后熄灭。
充电盒: 充电亮红灯, 充满电亮蓝灯。(低电时, 红灯闪烁直至熄灭)
- 🎵 语音拨号-长按MFB键1秒, 听到提示音释放。(仅支持有语音拨号功能的手机)
- 🔗 TWS 配对步骤-首次配对 (单个耳机使用时)
 - 蓝牙首次配对时, 请将蓝牙耳机和手机的距离控制在1米的范围内;
 - 关机状态下, 长按“MFB”键4秒, 开机后, 双击“MFB”键, 红绿灯交替闪烁;
 - 开启手机蓝牙功能, 搜索蓝牙耳机。
 - 选择“S030”耳机。
 - 输入配对密码“0000”(有些手机需要密码配对, 有些手机不需要密码配对。)
 - 配对失败后, 请重复上述操作;
 - 如果配对成功后, 绿灯闪烁。

功能介绍

- 🔗 一个耳机连接两个手机 (单个耳机使用时, 只能听歌)
 - 按配对步骤, 配对第一个手机后, 将手机蓝牙功能关闭, 再配对第二个手机;
 - 打开第一个手机的蓝牙功能, 手动连接第一部手机。
 - 🔗 注: 当两个耳机进行TWS连接后, 不能同时连接两个手机。
 - 🔗 TWS 配对方式 (两个耳机使用时)
 - 关机状态下, 同时长按两个耳机多功能键直到红绿灯交替闪烁, 两个耳机进入TWS配对状态;
 - 配对成功后, 左声道耳机 (耳机自动语音提示) 会自动进入配对状态;
 - 打开手机蓝牙功能, 打开“蓝牙搜索”或“添加新设备”选择“S030”, 确认。
 - 🔋 语音提示
 - 当开机时, 耳机会自动语音提示: “开机”。
 - 当关机时, 耳机会自动语音提示: “关机”。
 - 当配对成功时, 耳机会自动语音提示: “已连接”。
 - 当连接断开时, 耳机会自动语音提示: “已断开”。
 - 当电量低时, 耳机会自动语音提示: “电量低”。
- 备注: 部分功能操作会因手机的不同而有所改变, 请用户在实际操作时留意。

Features

- 🔋 Power on: Long press "MFB" for 4 seconds until green light turn on while headset is off.
Power off: Long press "MFB" for 3 seconds until green light turn off while headset is on.
- 📞 Answering a call: Short press the "MFB" button on your headset.
Ending a call: Short press the "MFB" on your headset.
Rejecting a Call: Press the end key on your phone or long press the "MFB" for 1 second on your headset.
- 📞 Redialing the Last Called Number: Double press the "MFB" button when headset is in standby mode.
- 🎵 Play/Pause: When you are listening to the music from the headset, you can short press the "MFB" button to play and pause.
- 🔄 Reset: When in charging, double press "MFB" button to clear pairing records, it is done until the indicator flashes in green.
- 📞 Tripartite telephone online:
During the call, click the "MFB" button to hang up the current call and answer the waiting call.
Double-click the "MFB" button switch the caller.
- 🔋 Low Power Alarm: When the headset is power on, if the battery voltage is lower than 3.3V, there will be a prompt and the red indicator light flashes every 20 seconds.
- 🔋 Low Power Shutdown: When the headset is power on, if the battery voltage is lower than 2.9V, the headset will shutdown automatically.

Features

- 🔋 Charging the headset: Put the headset in the charging dock, the lights turn red; after charging completed, the lights turn green and off.
Charging dock: The lights turn red when charging, the lights turn blue after completed. (When the charging dock in low battery status, the red light flashes till to be off.)
- 🎵 Voice dialing-on the status of standby, long press "MFB" for about 2 second.
- 🔗 Steps of Bluetooth pairing single headset
 - Pair the headset for the first time, the distance between the headset and your mobile phone would be better within 1 meter when pairing.
 - Long press "MFB" for about 4 seconds till green light turns on, then double click "MFB" till the red and green light flashes alternatively and enter into pairing mode.
 - Start mobile phone Bluetooth function.
 - Search Bluetooth device, choose "S030".
 - Input pair code "0000" (The password is required for some phones.)
 - Repeat above-mentioned steps if the pairing was unsuccessful.
 - The green light will flash if paired successfully.
- 🔗 Twin-Link connection (only for music listening when using one earbud only)
 - After paired the first mobile phone, please turn off the Bluetooth function of the first mobile phone, then pair to the second Bluetooth mobile phone.
 - Switch on the first mobile phone Bluetooth function, manually connect the first mobile phone.

Features

- Note: When two headsets in the stereo mode, can't connect two devices at the same time.
- 🎵 Voice prompt
 - When the headset is on, there will be the automatic voice prompt: power on
 - When the headset is off, there will be the automatic voice prompt: power off
 - When being connected successfully, there will be automatic voice prompt: connected
 - When being disconnected, there will be automatic voice prompt: disconnected
 - When the battery is low, there will be voice prompt: battery low
 - 🔗 Stereo pairing (when two headsets are used at the same time)
 - In the state of power off, press the "MFB" button until red light and green light flash alternately, the two headsets simultaneously into the stereo pairing state, the two headsets will be connected automatically.
 - After pairing is successful, the left channel headset (voice prompts Automatically) will into the pairing state automatically.
 - Turn on the Bluetooth function of the mobile, searching the (visible to paired devices) or (available devices), choose Bluetooth ID "S030" for pairing.
- Important: Different mobile phone brands or menu functions, the usage will be different. Please read your phone's manual carefully.

废弃电器处理

废弃电器和电子设备

本产品或附有如下标识的产品, 寿命结束时不应与其它家庭废物一起处理。

为了防止因废物受理不受控制而可能使环境或人身健康受到损害, 请将本产品与其它类型的废物分开, 并负责任地回收本产品, 以促进可持续地重复利用材料资源。



请与本产品的零售商或当地相关机构联系, 了解家庭用户对电子产品环保回收条例, 进行适当的回收。

企业用户应与其供应商联系并检查采购合同的条款和条件, 本产品不应与其他商业废品混在一起处理。

全国统一服务热线: 400-881-0138

客户服务时间: 周一至周五9:00-18:00 (节假日除外)

售后服务条例与说明

售后服务条例:

1. 咨询服务: 用户在使用产品前, 请仔细阅读本产品的使用说明书。在使用过程中遇到的如何问题, 均可与当地经销商联系, 或致电全国统一客服热线 400-881-0138
2. 包换服务: 包换期内(自购机之日起七日内), 正常使用出现了非人为故障, 请保持产品、配件和包装的完整(若外观不损坏、作保修处理)经检测确认故障后, 可选择换货或维修, 用户可到当地授权经销商处联系并处理。
3. 保修服务: 保修期内, 正常使用出现的非人为故障, 均可享受免费保修服务(主机一年内免费保修, 若人为损坏, 作收费维修处理)。
4. 收费维修服务: 产品在自购机之日起一年到三年内, 出现故障可收费维修, 用户需支付维修所产品的元件费、运输费及人工费。
5. 以下情况不在三包范围内, 本公司提供有偿服务:
 - ① 超过三包期限
 - ② 涂改三包凭证, 或序列号与产品本身不符
 - ③ 意外因素或人为导致的产品损坏(如: 未按使用说明书操作、维护或保管、安装错误造成的故障, 接入不合适的电源、进水、摔坏等)

- ④ 无有效三包凭证和有效发票 (能证明产品确属服务期内者除外)。
- ⑤ 因不可抗力如地震、火灾、水灾、雷击等导致的产品故障或损坏。
- ⑥ 未经本公司许可, 擅自拆卸、修理或改装。

关于售后服务的说明:

1. 购机日期以本凭证或购机发票为准, 不能提供有效证明的, 以生产日期为准。
2. 质量问题不包括用户个人对音质、音色等主观差异。
3. 外壳、说明书包装不在保修服务范围内。
4. 已停产机型, 本公司仅做功能性修复。
5. 经销商向您做出的非本公司保证的承诺, 本公司不承担任何责任。

经销商信息	产品型号	经销商名称
	产品序列号	联系电话
用户信息	用户地址	销售日期
	通讯地址	联系电话
	E-mail	

为了维护您的权益, 请您认真填写, 并妥善保管, 作为维修时的认证

Handling of the Waste Electrical

The waste Electrical

This marking shown on the product or its literature indicates that it should not be disposed with other household wastes at the end of its working life.

To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate this from other types of wastes and recycle it responsibly to promote the sustainable reuse of material resources.

Household user should contact either the retailer where they purchased this product or their local government office, for details of where and how they can take this item for environmentally safe recycling.

Business users should contact their supplier and check the terms and conditions of the purchase contract. This product should not be mixed with other commercial wastes for disposal.



Services Hot Line: 400-881-0138

Services time: AM 9:00 - PM 6:00
Monday to Saturday (holiday is exclusive)

Service Regulations and Explanation

After service

(A) Service system

1. Consultancy: Please read this user manual carefully before using this product. For any problem during using it, you can contact your seller.
2. Exchange service: within exchange time limit, for any indeliberate error during proper use, making sure the product as well as its accessories and package are all not damaged/ the appearance is damaged, it can only be repaired/ you can either have it exchanged for a new one or repaired after the error is tested and examined;
3. Warranty service: within the warranty time limit, for any indeliberate error that occurs during proper use, warranty service is free for no charge (the headphone has warranty service for free within one year; for any deliberate damage, the warranty service should be paid).
4. Charged warranty service: within three years counting from one year after the date the product was purchased, any error repair will be charged; and user should pay the repair components, freight and labor cost.

5. Any of the below situation is not in the warranty service, but we provide charged service:

- ① The warranty date is expired;
- ② The warranty card is altered, or the series number differs from that of the product;
- ③ Accidental or deliberate damage is done to the product (for example: improper use against the user manual, improper set up which causes error, plugging in unmatched power, exposed to water, fallen etc.)
- ④ cannot provide valid warranty card or invoice (other but can prove that it is within the service limit);
- ⑤ Any error damage caused by force majeure such as earthquake, fire, flood, lightning strike etc.
- ⑥ Deliberate assembling, repair or reform without permission from our company.

(B) Explanation of After Service:

1. The date of purchased should be in accordance with that of the invoice, any failure to provide the valid proof, is subjected to the production date.
2. Quality problem does not include user's personal preference to tone and timbre.
3. The shell and user manual package are exclusive to warranty service.
4. For the model that production has been stopped, we only provide functional repair.
5. We are not responsible for any promises by retailer other than our company.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.