

Product Description


Bluetooth standard:V4.0

Charging means:power adapter output(DC5V 150mA) Battery: High-capability rechargeable lithium polymer battery Bluetooth Operation:class 2

Profiles Supported:Headset/handsfree/A2DP/AVRCP/APT-X

Talk time: up to 8 hours Playing time: up to 8 hours Stand by time: 100 hours Special function:NFC Model name:G02 Brand name:DACOM FCC ID:WTDG02

- When being connected to Bluctooth DONGLE on PC,it can



Features

- Power on-short press the power on/off button for 1 second until the green indicator light flashes. Power off-With the headset power on, short press the power on/off button.indicator light goes off.
- Answering a call-Press the answer key on your phone or short press the MFB button on your headset.
- Ending a call-Press the end key on your phone or short press the MFB button on your headset.
- Rejecting a call-Press the end key on your phone or long press the "Volume Down" button for 2 seconds on your headset.
- Redialing the last called number-Double press the MFB button when headset is in standby mode.
- Play / Pause-When you are listening to the music from the headset, you can short press the MFB button to play and pause
- Previous/Next Track -Previous Track when press the "Volume up" 2 seconds. Next Track when press the "Volume down" 2 seconds
- Volume control-Volume will be "up" when short press the "Volume up" and will be "down" when short press the "Volume down".



Features

Voice Prompt

- When the headset is on, there will be the automatic voice prompt: power on
- When the headset is off, there will be the automatic voice prompt: power off
- When being connected successfully, there will be voice telling: your headset is connected
- When the battery is low, there will be voice telling:battery low When a call comes in, the headset will speak up the caller's phone number.
- Pair to your Bluetooth Phone
- Pair the bluetooth headset for the first time. The distance between the Bluetooth headset and your Bluetooth
- phone would be better within 1 meter when pairing. With the headset power off, hold and press MFB. button until the headset is in pairing status, red light and green light flash alternately.
- Start mobile phone bluetooth function.
- Search bluetooth device.
- Choose "G02"
- Input pair code "0000" (The password is required for some phones.)
- Repeat above-mentioned steps if the pairing was unsuccessful
- The green light will flash if paired successfully.



Features

- Connect two Bluetooth mobile phones at the same time
 - After paired the first mobile phone, please turn off the Bluetooth function of the first mobile phone, then pair to the
 - second Bluetooth mobile phone.
 Power off the Bluetooth headset and turn on the Bluetooth function of the first mobile phone. Then power on the Bluetooth headset, it will connect two mobile phones automatically.
- During a call, short press the MFB, hang up the current call, then answer the incoming call.
 - Double press the MFB to answer another incoming call while you are on one phone call, and switch between the two incoming calls
 - Short press the MFB to cut off the incoming calls one by

e: While two mobile phones are connecting one Bluetooth headset, ne functions of the Bluetooth headset will be restricted.

- Your headset uses a rechargeable battery, you must charge the battery fully before using the headset for the first time
 - Plugging the charging cable in the USB charge port.
- The red indicator light remains solid when charging.
 - The fully charging takes 2 hours.
 - The red indicator light goes out and the green indicator light remains solid when charging completed.



Features/Handling of the Waste Electrical

NFC Function:The mobile phone only need to touch the headset NFC detecting area when the headset is on.

The waste Electrical

This marking shown on the product or its literature indicates that it should not be disposed with other household wastes at the end of its working life

To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate this from other types of wastes and recycle it responsibly to promote the sustainable reuse of material resources

Household user should contact either the retailer where they purchased this product or their local government office, for details of where and how they can take this item for environmentally safe recyclina.

Business users should contact their supplier and check the terms and conditions of the purchase contract. This product should not be mixed with other commercial wastes for disposal.



Services Hot Line: 400-881-0138

Services time: AM 9:00 - PM6:00 Monday to Saturday (holiday is exclusive)



Service Regulations and Explanation

After service

(A) Service system

1. Consultancies: Please read this user manual carefully before using this product. For any problem during using it, you can either contact the local retailer or call our customer service Hot

Line: 400-881-0138

- 2. Exchange service: within exchange time limit, for any indeliberate error during proper use, making sure the product as well as its accessories and package are all not damaged (if the appearance is damaged, it can only be repaired) you can either have it exchanged for a new one or repaired after the error is tested and
- 3. Warranty service: within the warranty time limit, for any indeliberate error that occurs during proper use, warranty service is free for no charge (the speaker has warranty service for free within one year; for any deliberate damage, the warranty service should be paid).
- 4. Charged warranty service: within three years counting from one year after the date the product was purchased, any error repair will be charged; and user should pay the repair components. freight and labor cost.

- 5. Any of the below situation is not in the warranty service, but we provide charged service:
- ① The warranty date is expired:
- 2 The warranty card is altered, or the series number differs from that of the product;
- ③ Accidental or deliberate damage is done to the product (for example: improper use against the user manual, improper set up which causes error, plugging in unmatched power, exposed to water, fallen etc.)
- (4) cannot provide valid warranty card or invoice (other but can prove that it is within the service limit); (5) Any error damage caused by force majeure such as
- earthquake,fire, flood, lightning strike etc. Deliberate assembling, repair or reform without permission from
- our company.

(B) Explanation of After Service:

- 1. The date of purchased should be in accordance with that of the invoice, any failure to provide the valid proof, is subjected to the production date.
- 2.Quality problem does not include user's personal preference to tone and timbre.
- 3. The shell and user manual package are exclusive to warranty 4. For the model that production has been stopped, we only provide
- functional repair 5.We are not responsible for any promises by retailer other than
- our company.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.