# User manual

CAUTION: To use this device properly, please read the user's guide before installation.

#### Features:

- Classic full-size keyboard layout (multiple keyboard languages)
- 1-port USB 2.0 Full Speed USB Hub
- Seven reprogrammable hot keys
- Multimedia pod with audio/video controls, including key for opening media player
- Common Microsoft Windows shortcuts are highlighted on front skirt (front surface) of keys (on supported language layouts)
- Three degrees of keyboard tilt adjustment
- Detachable palm/wrist rest with a smooth rubberized coating
- Access button
- Attach via USB connector

#### Warranty

1 year Limited - customer carry-in exchange

Technical specifications

Electrical specifications as known at time of announcement 5 V, 300mA

Physical, environmental, and compatibility specifications as known at time of announcement

#### **Operating temperature**

- Between 10 degrees Celsius and 40 degrees Celsius
- Between 50 degrees Fahrenheit and 104 degrees Fahrenheit

#### **Relative humidity**

Operating: between 8% and 80%

### **Hot Key Functions**

益	(www.Home): Starts the default web browser and links to the web browser home page.
$\Diamond$	(www.Back): Links to the previous viewed page in web browser or file browser.
$\Rightarrow$	(www.Foward): Links to the next viewed page in web browser or file browser.
,ī	(Media): Starts the default media player.
□-	(Volume Down): Reduces the system audio volume.
M	(Previous track): Plays previous media track.
⊳/II	(Play/Pause): Plays or pauses the current media track.
	(Stop): Stops the current media track.
KK	(Next track): Plays next media track.
<b>□</b> +	(Volume Up): Increases the system audio volume.
$\bowtie$	(Mute): Silences the system audio.
Ð Ø	(www.Refresh): Reloads the web page contents in a web browser.  (www.Search): Launches the Search pane in Internet Explorer or file browser.  -This Hot Key may not function as expected on other web browsers.
*	(www.Favorite): Launches the Favorite Pane in Internet ExplorerThis Hot Key may not function as expected on other web browsers
$\bowtie$	(E-mail): Launches the default E-mail program.
	(My Computer): Launches the file browser and link to My Computer page.  -This Hot Key may not function as expected on other web browsers
*****	(Calculator): Launches the Calculator program.

## **FCC Requirement**

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

You are cautioned that changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.

M/N: SSKSV207xxx FCC ID: X7LSS207208

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.