Installing the Batteries

This RF2.4GHz Touch keyboard use Built in lithium -ion rechargeable battery.

Charging step

This wireless touchpad built - in rechargeable battery

1.When your touch pad not working smoothly due to lack of electricity , according to Figure 1 to charge the touchpad.

2.When your touch pad is fully charged , unplug the charging cable according to Figure 2 direction.



Conecting the Receiver


The receiver is insert to USB port immediate, or by a extra USB cable.







1. Connect the USB plug to USB port of your computer.



NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- □ Reorient or relocate the receiving artenna.
- $\hfill \square$ Increase the separation between the equipment and receiver.
- □ Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- ☐ Consult the dealer or an experienced radio/TV technician for help.

- English: "

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

- (1) this device may not cause interference, and
- (2) this device must accept any interference, including interference that may cause undesired operation of the device."

- French:'

Le pr é sent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autoris é e aux deux conditions suivantes :

- (1) l'appareil nedoit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radio é lectrique subi, m ê me si le brouillage est susceptible d'en compromettre le fonctionnement."

Multimedia Hotkeys functions

FN+ESC=Media Player FN+F7= Web home FN+F1=Play/Pause FN+F8= Search FN+F2=Previous Track FN+F3=Next Track FN+F10= Email FN+F4=Volume Up FN+F11=Screen Lock FN+F5=Volume Down FN+F12= My computer FN+F6= Mute (Windows) FN+Insert= Calculator

Restoring factory default settings

when you find this wireless keyboard doesn't work,you can make the keyboard in working condition by restoring back to factory default settings.

- 1:check the battery volume is normal; please ob serve the Keyboard red light flashing , flashing red to indicate low battery , please charge
- 2.for this keyboard,you can press the keys of "Esc" and "K". at the same time then
- 3.insert the USB receiver onto the USB port the PC or notebook

Other Considerations

- 1.power-saving design : When the keyboard does not take any action about 2 seconds into hibernation , press any KEY screen wake .
- 2 .When you press the FN + F11 , the keypad keys do not output the value of users to leave after the others in order to prevent false triggering .

FCC STATEMENT:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.


Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

2

Model: SK-042AG

Instruction Manual

RF 2.4GHz keyboard





CAUTION: To use this device properly, please read the user's guide before installation.