

K82G Keyboard User Manual(for Dongle and Keyboard)

This keyboard has been shipped with 3 AAA batteries installed and is already paired to its respective dongle. Simply plug the dongle into a PC and wait for USB to discover device and install drivers; follow the systems prompts.

A Note on Stuck Keys

If a key(s) is held down for approximately 30 seconds, the keyboard will send “all keys released” data to the dongle and “go to sleep” to conserve battery power.

Battery Instructions

The keyboard has a low battery LED that will illuminate during poor battery conditions. Be sure to change all three batteries, else the low battery will drastically shorten the life of the fresh battery(s). The pairing is maintained if the batteries are changed.

Note:

When replacing batteries, do not touch the touchpad. If touchpad motion becomes erratic, then double tap on its surface to recalibrate.

Pairing Instructions

1. User brings the keyboard approximately 18” from the desired dongle, then press Fn + Esc on the keyboard to enter pairing mode. The pairing LED on the keyboard will be turned ON.
2. The keyboard will start searching for dongles for pairing; this will take approximately 10 seconds. The keyboard will select the dongle with strongest RF signal if more than one dongle is within range. The pairing LED on the keyboard will turn “off” once it has paired with a dongle. The pairing is maintained if the batteries are changed.

Un-pairing Instruction

1. Press the Fn, Right Shift and Pairing key to un-pair the keyboard from its dongle. The pairing LED will flash. Follow the steps above for pairing the desired dongle.

FCC label for Keyboard

Heng Yu
Model No.:K82G
FCC ID: XENK82GKB
MADE IN CHINA
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

FCC label for Dongle



FCCID:XENK82GDB

Appendix

Changes or Modifications not expressly approved by the party responsible could void the user's authority to operate this device.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.