User manual

Model:WSRE302,WSRE301 Brand:WISTAR

1.Product appearance



RE302 5-channel



back

2.Technical data

Power : 3V model : CR2032	Currency : ≤12mA
Work temperature : -20℃～60℃ (non LCD emitter)	Code: rolling code
Work temperature : -10℃～60℃ (LCD emitter)	Frequency : 433.92MHz
Battery Rated Voltage: 3V Capacity: 210mAh	

3.Code learning

01.Single channel

Short press learning button at back side once, now the code learning is successful.

4.Channel emitter

Short press the Channel Switch Button to select a channel (from 1-5),once selected, the corresponding light will shine.

Then short press learning button on the back once, the code learning of current channel is successful. So do other channels.

5.Group control(5-channel emitter)

Short press the Channel Switch Button to select a channel(from 1-5), once selected, the corresponding light will shine.

Note: if all of the lights are on, it means the emitter is in Group Control state.

FCC Caution.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.