

Flip and Rip

RC Stunt Vehicle

User Guide




**SAVE THESE INSTRUCTIONS.
READ COMPLETE INSTRUCTIONS BEFORE USE.**

#XC9946


© 2012 EB Brands

Congratulations on your new EXRC purchase! EXRC dragsters dominate the road with superior speed and control. Now that you're an honorary EXRC dragster, we recommend reading through this manual thoroughly before attempting your first race. Inside this manual, you will find driving control tips, safety precautions and care instructions to keep your EXRC vehicle in tip-top shape. Follow the instructions, and use your EXRC vehicle to feed your need for speed and race toward the checkered flags! Ladies and gentlemen, start your engines!

VEHICLE LAYOUT



CONTROLLER LAYOUT




BATTERY INSTALLATION

Operation requires 4 "AA" batteries for car and one 9V battery for remote control.


Remote


1. Carefully remove remote control from package
2. Using a Phillips-head screwdriver, remove the screw from the battery compartment cover and insert 9V battery. Be sure to follow the battery polarity (+ and -) drawing on the product.
3. Replace the battery compartment cover and secure with the screw.



Vehicle

1. Carefully remove vehicle from package.
2. Locate the battery compartment on the back of each item.
3. Swivel latches on bottom of car to release the battery pack and insert 4 AA batteries. Be sure to follow the battery polarity (+ and -) drawing on the product.
4. Slip battery compartment back into the vehicle and secure latches.
5. Turn the ON/OFF switch located on the bottom of the vehicle to ON position. If batteries have been installed properly, the LED lights within the vehicle will turn on when you switch the vehicle to the ON position.





HOW TO DRIVE

1. To move forward: Press both joy sticks forward at the same time.
2. To move backward: Press both joy sticks backward at the same time.
3. To do reverse right turn: Press Right joystick forward
4. To do reverse left turn: Press Left joystick forward
5. To spin on all 4 wheels: Press the Left and the Right joystick in opposite directions.
6. To wheelie spin: Press Right or Left joystick backward.

CARE AND HANDLING

- To avoid damage to the vehicle, never drive it on a wet surface, sand, mud, or snow.
- Do not expose the vehicle to extreme temperatures, or operate during thunderstorms or rain.
- Don not submerge car or controller in water.
- Never operate your car on the street, highway or in confined or crowded areas; do not use people or animals as obstacles. Avoid operating near small children.
- Do not run the car into furniture, objects or hard surfaces, doing so will damage the car.
- Keep fingers, hair and loose clothing away from the tires, gears and motor while car is on.
- Do not leave car or transmitter outside near sources of heat or under direct sunlight for long periods of time; or outside overnight as dampness harms interior components.
- Remove all batteries when not in use to avoid accidental operation.
- Adult supervision is recommended when using this car.
- To clean vehicle, use a damp cloth then wipe dry. Do not use chemical cleaners.
- Long periods of playtime can generate a high heat level, which causes wear and tear. To extend product life, allow 10 minutes to cool down before installing new batteries.

⚠ CAUTION – Battery Safety Information

- Non-rechargeable batteries are not to be recharged
- Rechargeable batteries must be removed before recharging
- Rechargeable batteries should only be recharged under adult supervision
- Do not mix alkaline, standard (carbon-zinc), or rechargeable batteries
- Exhausted batteries are to be removed
- Do not mix old and new batteries
- Do not dispose of product in fire; batteries may explode or leak
- If this product will not be used for an extended period, remove batteries from the product
- The supply terminals are not to be short-circuited
- Batteries are to be inserted with correct polarity
- Clean the battery contacts and also those of the product prior to battery installation
- As always, dispose of batteries in an eco-friendly manner

Caution: The user is cautioned that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.