





Ref 10 dBm *Att 20 dB *RBW 100 kHz Delta 1 [T1]
*VBW 300 kHz 0.12 dB
SWT 2.5 ms 12.080000000 MHz



Plot: B2A1




Ref 10 dBm *Att 20 dB *RBW 100 kHz Delta 1 [T1]
*VBW 300 kHz 0.17 dB
SWT 2.5 ms 12.080000000 MHz



Plot: B2B1




Ref 10 dBm *Att 20 dB *RBW 100 kHz Delta 1 [T1]
*VBW 300 kHz 0.33 dB
SWT 2.5 ms 12.08000000 MHz



Plot: B2C1




Ref 10 dBm *Att 20 dB *RBW 100 kHz Delta 1 [T1]
*VBW 300 kHz 0.69 dB
SWT 2.5 ms 16.56000000 MHz



Plot: G2A1




Ref 10 dBm *Att 20 dB *RBW 100 kHz Delta 1 [T1]
*VBW 300 kHz 0.37 dB
SWT 2.5 ms 16.560000000 MHz



Plot: G2B1



Ref 10 dBm *Att 20 dB *RBW 100 kHz Delta 1 [T1]
*VBW 300 kHz 0.31 dB
SWT 2.5 ms 16.560000000 MHz



Plot: G2C1