





Ref 10 dBm      \*Att 20 dB      \*RBW 3 kHz      Marker 1 [T1 ]  
\*VBW 10 kHz      -22.04 dBm  
\*SWT 500 s      2.412866500 GHz



Plot: B3A1




Ref 10 dBm      \*Att 20 dB      \*RBW 3 kHz      Marker 1 [T1 ]  
\*VBW 10 kHz      -22.28 dBm  
\*SWT 500 s      2.437837000 GHz



Plot: B3B1




Ref 10 dBm      \*Att 20 dB      \*RBW 3 kHz      Marker 1 [T1 ]  
\*VBW 10 kHz      -21.98 dBm  
\*SWT 500 s      2.462871500 GHz



Plot: B3C1




Ref 10 dBm      \*Att 20 dB      \*RBW 3 kHz      Marker 1 [T1 ]  
\*VBW 10 kHz      -22.91 dBm  
\*SWT 500 s      2.412136500 GHz



Plot: G3A1




Ref 10 dBm \*Att 20 dB \*RBW 3 kHz \*VBW 10 kHz \*SWT 500 s Marker 1 [T1 ]  
-22.39 dBm  
2.437141000 GHz



Plot: G3B1



Ref 10 dBm \*Att 20 dB \*RBW 3 kHz \*VBW 10 kHz \*SWT 500 s Marker 1 [T1 ]  
-21.92 dBm  
2.462142500 GHz



Plot: G3C1