





Ref 10 dBm *Att 20 dB *RBW 100 kHz Delta 1 [T1]
*VBW 300 kHz -48.18 dB
SWT 250 ms -1.741803000 GHz



Plot: B4A1




Ref 10 dBm *Att 20 dB *RBW 100 kHz Delta 1 [T1]
*VBW 300 kHz -45.97 dB
SWT 2.3 s 21.850000000 GHz



Plot: B4A2




Ref 10 dBm *Att 20 dB *RBW 100 kHz Delta 1 [T1]
*VBW 300 kHz -46.69 dB
SWT 250 ms -1.739304000 GHz



Plot: B4B1




Ref 10 dBm *Att 20 dB *RBW 100 kHz Delta 1 [T1]
*VBW 300 kHz -46.74 dB
SWT 2.3 s 21.919000000 GHz



Plot: B4B2




Ref 10 dBm *Att 20 dB *RBW 100 kHz Marker 1 [T1] -5.16 dBm
*VBW 300 kHz 2.465014000 GHz
SWT 250 ms



Plot: B4C1




Ref 10 dBm *Att 20 dB *RBW 100 kHz Delta 1 [T1] -45.43 dB
*VBW 300 kHz 21.827000000 GHz
SWT 2.3 s



Plot: B4C2




Ref 10 dBm *Att 20 dB *RBW 100 kHz Delta 1 [T1]
*VBW 300 kHz -44.14 dB
SWT 250 ms -654.738000000 MHz



Plot: G4A1




Ref 10 dBm *Att 20 dB *RBW 100 kHz Delta 1 [T1]
*VBW 300 kHz -38.36 dB
SWT 2.3 s 21.873000000 GHz



Plot: G4A2




Ref 10 dBm *Att 20 dB *RBW 100 kHz Delta 1 [T1]
*VBW 300 kHz -46.77 dB
SWT 250 ms -1.944222000 GHz



Plot: G4B1




Ref 10 dBm *Att 20 dB *RBW 100 kHz Delta 1 [T1]
*VBW 300 kHz -40.63 dB
SWT 2.3 s 21.712000000 GHz



Plot: G4B2




Ref 10 dBm *Att 20 dB *RBW 100 kHz Delta 1 [T1]
*VBW 300 kHz -47.40 dB
SWT 250 ms -614.754000000 MHz



Plot: G4C1



Ref 10 dBm *Att 20 dB *RBW 100 kHz Delta 1 [T1]
*VBW 300 kHz -41.20 dB
SWT 2.3 s 21.758000000 GHz



Plot: G4C2