


# **VEHICLE INSTRUCTIONS**



### HOW TO USE VEHICLE

- Remove battery cover with screwdriver.
   Insert 4 x 1.5v LR03 AAA batteries.
- 3. Close battery cover with screwdriver

8.5"

Turn power on.

If vehicle "pulls" left or right, counteract misalignment by using steering alignment lever. (Example: If vehicle veers left, click lever towards the right of center and test until alignment is corrected. If vehicle veers right, click lever to the left of center and test until alignment is corrected.)

CAUTION: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no quarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- -Consult the dealer or an experienced radio/TV technician for help.

\*\*This device and its antenna must not be co-located or operating in conjunction with any other antenna or transmitter

This radiocommunication device complies with all the requirements of Industry Canada Standard RSS-310.

#### INFORMATION FOR THE DOMESTIC APPLIANCES USERS

In accomplishment of the directives 2002/95/CE, 2002/96/CE and 2003/108/CE, relating to the reduction of the usage of dangerous materials into the electric and electronic appliances, and also to the waste disposal. The symbol of the crossed bin which is on the device or on the packaging signifies that the product at the end of its working life must be collected separately from the other waste materials. Therefore, the user will have to give the appliance at the end of its life to the appropriate centers for the separate collection of electronic and electrotechnical wastes, or give it back to the retailer while purchasing a new device of equivalent kind, in reason of one to one. The appropriate separate collection for the following sending of the unused appliance to the waste recycling, to the treatment and to the disposal compatible with the environment contributes to avoid possible negative effects on the environment and on the health and favours the reuse and /or recycling of the materials which the appliance is made of. The unauthorized disposal of the product by the user involves the application of the sanctions of which at the current regulations of law. For further information related to the collecting systems contact the local competent authorities.

Contents and color may vary slightly from images shown Conforms to ASTM F963 standards. Please retain packaging and manual for future reference



Irwindale, CA 91706, USA www.nkok.com









# **OPERATOR'S MANUAL**



If you have questions or difficulty operating this toy DO NOT RETURN IT TO THE STORE Call us Toll-Free: 888-656-5869

- Friday between 10:00am - 4:00 pm Pacific Standard Time or email us at: customerservice@nkok.com



### **INCLUDED COMPONENTS**

