

<p>BOOX Nova2 Series Quick Start Guide</p> <p>© 2019 Boox. All rights reserved. For more information, please visit www.boox.com.</p>	<p>BOOX Nova2 E Ink Tablet</p> <p>Product & Accessories</p> <p>Optional Accessories:</p>	<p>BOOX Nova2 E Ink Tablet</p> <p>Safety</p> <p>Declaration:</p> <p>This is a public safety notice. Please do not use the device in situations where it could be a distraction or cause harm. For example, do not use the device while driving or operating heavy machinery. The device is not intended for use in hazardous environments. For more information, please refer to the user manual.</p>	<p>BOOX Nova2 E Ink Tablet</p> <p>Front View:</p>	<p>BOOX Nova2 E Ink Tablet</p> <p>Back View:</p> <p>When your BOOX is off, press the power button and hold it for 10 seconds to turn the device on. When your BOOX is on, press the power button and hold it for 10 seconds to turn the device off.</p>	<p>BOOX Nova2 E Ink Tablet</p> <p>Interface Introduction:</p> <ul style="list-style-type: none"> Home Page Taskbar Content Area Function Area Home Page (Detailed) Taskbar Reading Section Reading Menu 	<p>BOOX Nova2 E Ink Tablet</p> <p>Touch Gestures:</p> <p>Horizontal slide on the screen:</p> <ul style="list-style-type: none"> Slide to the right to go to the next page. Slide to the left to go to the previous page. <p>Vertical slide on the screen:</p> <ul style="list-style-type: none"> Slide up to go to the next page. Slide down to go to the previous page. 	<p>BOOX Nova2 E Ink Tablet</p> <p>FAQS</p> <ol style="list-style-type: none"> How do I turn on the device? <ul style="list-style-type: none"> Press the power button for 10 seconds to turn the device on. When the device is on, the screen will show the home page. The screen will be blank if the device is off. How do I charge the device? <ul style="list-style-type: none"> Connect the USB-C cable to the device and the power adapter. When the device is charging, the screen will show the charging status. When the device is fully charged, the screen will show the battery level. How do I use the device? <ul style="list-style-type: none"> Press the power button to turn the device on. Press the home button to go to the home page. Press the taskbar button to go to the taskbar. Press the function area button to go to the function area. Press the home page button to go to the home page. Press the taskbar button to go to the taskbar. Press the reading section button to go to the reading section. Press the reading menu button to go to the reading menu. How do I protect my device? <ul style="list-style-type: none"> Use a screen protector to protect the screen. Use a protective case to protect the device. Do not use the device in hazardous environments. Do not use the device while driving or operating heavy machinery.
---	---	--	---	---	---	--	---

FCC Statement

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment does not emit radio frequency energy and is therefore not subject to the FCC Part 15.207. These limits are designed to provide reasonable protection against harmful interference in a residential environment.

This equipment operates with an antenna with frequency range of 1.57-1.62 GHz and is subject to the FCC Part 15.207. These limits are designed to provide reasonable protection against harmful interference in a residential environment.

Use of this equipment with an antenna that is not approved by the FCC may cause harmful interference to radio communications. Users are cautioned that interference will not occur in particular situations. If the equipment does cause harmful interference to radio or television reception, you can be relieved of the liability by stopping use of the equipment.

Changes to equipment that are not approved by the FCC may void the warranty.

Interference to reception:

- Changes to equipment or equipment settings may void the warranty.
- Changes to equipment or equipment settings may void the warranty.
- Changes to equipment or equipment settings may void the warranty.

Responsible Business Partner

This device complies with FCC equipment rules and is subject to the following conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. The manufacturer will not be responsible for modifications or changes to the equipment.