Frequency Band = Band 854 – 862 MHz, Test Frequency = low, Direction = RF downlink, Signal Type = CW
(S01_AA01)



Frequency Band = Band 854 – 862 MHz, Test Frequency = mid, Direction = RF downlink, Signal Type = CW
(S01_AA01)



Frequency Band = Band 854 – 862 MHz, Test Frequency = high, Direction = RF downlink, Signal Type = CW
(S01_AA01)





Date: 23.SEP.2019 19:53:51

BE measurement

Frequency Band = Band 809 – 817 MHz, Test Frequency = low, Direction = RF uplink, Signal Type = CW
(S01_AA01)



Frequency Band = Band 809 – 817 MHz, Test Frequency = mid, Direction = RF uplink, Signal Type = CW
(S01_AA01)



Frequency Band = Band 809 – 817 MHz, Test Frequency = high, Direction = RF uplink, Signal Type = CW
(S01_AA01)



Frequency Band = Band 862 – 869 MHz, Test Frequency = low, Direction = RF downlink, Signal Type = CW
(S01_AA01)



Frequency Band = Band 862 – 869 MHz, Test Frequency = mid, Direction = RF downlink, Signal Type = CW
(S01_AA01)