

0
P
I
E
R
R

2795-011 remote control user guide

date: 2018-05-04

version: 1

please note: this document must not be shared with third parties without prior written consent from ruwido austria gmbh

revision history

version	creation date	author	comments
V1	2018-05-04	Ralph Leblhuber	initial version

table of content

1	user operating instructions.....	4
1.1	manual pairing	4
1.2	switching between modes	4
1.3	factory reset	4
1.3.1	factory default settings.....	4
1.4	power control STB and TV.....	5
1.5	notes	5
2	declaration.....	6

1 user operating instructions

1.1 manual pairing

- power on STB
- press "**home**" and "**pay/pause**" keys for 3 sec to start pairing process (continues red flashing)
 - ➔ LED will stop flashing red if pairing was successful
- to delete pairing from remote control press "**home**" and "**right**" keys for 3 seconds to delete pairing
 - ➔ LED will flash 4 times red if pairing deletion was successful

1.2 switching between modes

- press and hold for a minimum of 3 seconds

" home " + " up " (for BLE/rstep)	factory default setting
" home " + " down " (for rstep)	IR fallback mode

 - ➔ LED flashes green twice

1.3 factory reset

- to set remote control back to factory mode press and hold "**home**" + "**left**" key for a minimum of 3 seconds
 - ➔ LED will flash 4 times red

1.3.1 factory default settings

- no TV programmed
- start transparent pairing with rstep
- factory default setting: BLE mode (rstep)

1.4 power control STB and TV

- no devices programmed
 - power button only power toggles STB
- tv programmed
 - power button power toggles tv and stb
 - volume +/- is controlling tv

1.5 notes

- pairing information will remain if batteries are being removed / changed
- mode settings will remain if batteries are being removed / changed
- for TV programming online TV database support and APIs are required

2 declaration

User Information FCC 15.21:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Part 15 Statement. FCC 15.19/RSS Gen Issue 3 Sect. 7.1.3

This device complies with Part 15 of the FCC Rules and with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Statement Class B Digital Device FCC 15.105:

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ TV technician for help.

OPINION