



User manual

Model no: 2035135 Rating: 5V 200MA

Main Unite:

- this section include the photo of the product and the overview of the main unit



- A: Power on/Power off
Also refer to MFB (Skull Button) below mentioned
- B: Volume+
Increase volume and track forward
- C: Volume-
Decrease volume and track backward

To Enter Pairing Mode:

- Make sure the Giro Device is in **OFF** mode
- Long Press MFB (Skull Button)(refer to A point) for **5** seconds

- While in pairing mode, the LED will alternate flashing Blue/Red

In STANDBY mode , Blue LED will fast flash two times every 3 secs.

To Power On:

- Make sure Giro is in OFF mode
- Long Press MFB (Skull Button) (refer to A point) for 3 seconds
- While Power On, the LED will flash Blue
- Giro will search and AUTO connect with previous paired phone for 3 seconds
- If previous phone is not available, it will enter STANDBY mode
- Can MANUALLY connect previous phone in STANDBY mode by phone operation
- Please note cannot pair a NEW phone in STANDBY mode
- To pair a NEW phone that has never been paired before, need to start Pairing Mode process

To Power Off:

- While Giro is in “Power ON” or “STANDBY” mode
- Long Press MFB (Skull Button) (refer to A point) for 3 seconds
- If in STANDBY mode for **30 mins**, **Giro Device** will automatically Power off

To Answer Phone Call, Play/Pause Music:

- Short Press MFB (Skull Button) (refer to A point)
- Music will resume after hanging up call

Volume Up:

- Short Press Volume Up Button (+)
- Will have audible tone sound when Max volume is reached
- 15 steps of volume control up

Volume Down:

- Short Press Volume Down Button (-)
- Will have audible tone sound (mute) when Min volume is reached
- 15 steps of volume control down

Track Forward:

- Long Press Volume Up Button (+)

Track Backward:

- Long Press Volume Down Button (-)

Tested Line of Sight Range of BT Connection:

- 12 meters

Battery Playback Time:

- 7 to 7.5 hours

Charging:

- Approximately 1.5 Hours
- LED will display solid Red when charging
- When Charge Full, LED will turn off

Low Battery Status Indicator:

- LED will display flashing Red
- Will have audible beeping indication every 30 seconds when battery is low



Your product contains batteries covered by the European Directive 2006/66/EC, which cannot be disposed with normal household waste.

Please inform yourself about the local rules on separate collection of batteries because correct disposal helps to prevent negative consequences for the environmental and human health.

Caution:

Risk of explosion battery is replaced by an incorrect type.

Dispose of used batteries according to the instructions

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions :

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

- (1) this device may not cause interference, and
- (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication.

Conformément à la réglementation d'Industrie Canada, le présent émetteur radio peut fonctionner avec une antenne d'un type et d'un gain maximal (ou inférieur) approuvé pour l'émetteur par Industrie Canada. Dans le but de réduire les risques de brouillage radioélectrique à l'intention des autres utilisateurs, il faut choisir le type d'antenne et son gain de sorte que la puissance isotrope rayonnée équivalente (p.i.r.e.) ne dépasse pas l'intensité nécessaire à l'établissement d'une communication satisfaisante.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.