


### Anechoic chamber setup


Position 1 – Non flush







Position 2 – Non flush







Position 1 – Metallic support





Position 2 – Metallic support





### Anechoic chamber test site


#### Pre-measure below 30 MHz



### Pre-measure between 30 MHz to 200 MHz




### Pre-measure between 200 MHz to 1000 MHz




### Open area setup

Position 1 – Non flush





Position 2 – Non flush






Position 1 – Metallic support






Position 2 – Metallic support







# Open area test site

### Measure below 30 MHz



### Measure between 30 MHz to 200 MHz





### Measure between 200 MHz to 1000 MHz





### Conducted measurement setup

## Non flush







With metallic support





