
Driveway Alert

Remote sensor




Sun Blocker


Narrow window adaptor

Sensing window


Battery installation




Open the back cover by unlock the screws




Replace the back cover as the diagram



Install the 4 AA batteries into the battery compartment as the indication on the compartment




Lock the screws



Replace sun blocker


Switch inside the transmitter




Mark the 4 hole on the wall using a pencil.

Requires an electric drill for holes to fix the Sensor with the provided ram plug and screws.

 $^{\circ}$




Mounting the sensor with screw provided



Adjust the sensor to make a good operation angle

Detection Distance and Angle



Pairing


This sensor works with the receiver (chime) and must be paired before using

- Step 1: Insert battery to the sensor.
- Step 2: Insert batteries to the receiver (chime).
- Step 3: Enter pairing mode for receiver (chime unit).

 Press and hold the● learning button 3 seconds. The LED
 #1 will flash.
- Step 4: Press the button again to move to the zone you want to pair with.

Press press melody selector to scroll through the melodies. Once you hear your preferred melody, do not press again as it is now selected.

There are 18 melodies & sound effects in sequence.



Step 5: Once you have selected the zone and melody, trigger the sensor by pressing test button once.

If successful, the receiver will generate a short tone. Press the ● button to exit pairing mode, the system is now ready to use.



Code Conflict

If the PIR sensor coding is the same as another transmitter you must change the code. When you have changed the code, you need to repair the PIR sensor.



Press and hold the test button, insert the battery and hold the button 5 seconds. The LED will flash 5 time when a new code is generated

FCC Statement:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- * Reorient or relocate the receiving antenna.
- * Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: Modifications to this product will void the user's authority to operate this equipment.





