

## Remote Control Outlet Adapter

Stops the wasted electricity that devices generate even when not in use

## INSTRUCTIONS

- 1. Plug the Remote Control Outlet Adapter into an indoor, grounded wall outlet.
- 2. Plug an electrical device into the Remote Control Outlet Adapter.
- 3. Press the remote control to power ON your device as indicated by GREEN LED light on the right side of the remote control.
- 4. When finished using the device plugged into the Remote Control Outlet Adapter, turn the device OFF as usual.
- 5. Then press the switch on the remote control to cut OFF standby power to the device.
- 6. When you want to use the device again, FIRST use the remote control to activate power into Remote Control Outlet Adapter.
- 7. Then turn ON the device you wish to use.
- 8. REPEAT steps 4 & 5 as necessary.

## REMINDER.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- —Reorient or relocate the receiving antenna.
- —Increase the separation between the equipment and receiver.
- —Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- —Consult the dealer or an experienced radio/TV technician for help.

EOAREM-002 125V~60HZ-10A TUNGSTON LOAD..240W

www.practecol.com

save &sustain simply™

