

## IK800 Dual Mode Scissor Keyboard Manual



### Specification

Item	Specification
Keys	110
Switch	Scissor Switch
Dimension	427.4*122.9*12.2MM
Weight	525g±20g
Voltage	3.7V
Working Current	≤150mA
Sleeping Current	≤50uA
Backlit	White
Battery	800mAh Lithium Battery
Compatible systems	Windows, Android, IOS ,Mac, Linux

### Fn Shortcuts & Single Key Function

Keys	Fn Shortcuts Function	Single Key Function
	FN+F1: F1 key	Mute
	FN+F2: F2 key	Volume Decrease
	FN+F3: F3 key	Volume Increase
	FN+F4: F4 key	Previous song
	FN+F5: F5 key	Play/Pause
	FN+F6: F6 key	Next Song
	FN+F7: F7 key	Screen Brightness Decrease
	FN+F8: F8 key	Screen Brightness Increase
	FN+F9: F9 key	Select All
	FN+F10: F10 key	Copy
	FN+F11: F11 key	Paste
	FN+F12: F12 key	Cut
	Fn shortcuts and F1-F12 single keys function would be swapped.	Return
	Fn+Space: Adjust Backlit Brightness	Space

### Keyboard Layout Swapping

	Fn+Q: Swap to Android layout	Q
	Fn+W: Swap to Windows layout	W
	Fn+E: Swap to Mac layout	E
	Fn+R: Swap to IOS layout	R

### 2.4GHz Connectivity

- 2.4GHz connectivity: Keyboard could be connected via the USB receiver.

尺寸85\*110，双面印刷

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

The devices has been evaluated to meet general RF exposure requirement, the device can be used in portable exposure condition without restriction