

Phone Specifications
Dimensions (WxDxH): 92mm*50mm*13.8mm
Lithium battery
Rated capacity: 3.7V 700mAh
Continuous standby duration: (Relates to network status) 120 hours
Continuous conversation duration: (Relates to network status) 2.5-3 hours
Please refer to their labels for other data related to the battery and the charger
USB cable: shielded cable with cores

1 Phone overview



2 Getting started

2.1 Installing the SIM Cards

An SIM card carries useful information, including your mobile phone number, PIN (Personal Identification Number), PUK (PIN Unlocking Key), IMSI (International Mobile Subscriber Identity), network information, contacts data, and short messages data.

- 1) Hold the Power key for a while to power off the mobile phone.
- 2) Pull the middle-bottom breach of the back cover outward and then lift the back cover away.
- 3) Lift the battery away.



- 4) Insert the SIM card into the SIM card slot lightly with the corner cutting of the card aligning to the notch of the slot and the gold plate of the card facing downward, till the SIM card cannot be further pushed in.



5) With the metallic contacts of the battery facing the metallic contacts in the battery slot, press the battery down until it locks into place, then fix its back cover.



Linking to the Network

After the SIM card and the mobile phone are successfully unlocked, the mobile phone automatically searches for an available network.

3 Input method
To Shift Entry Methods

Tap the left-top icon of phone screen to switch between input methods.

English Input

Tap the keypad icon on the phone screen to pop out a keypad simulator. Each of the number keys 1 to 9 is used to represent multiple characters. Quickly and continuously press a key till the character you want appears. Input the next character after the cursor moves.

4 Using the Menus

Messages

You are able to create, read, send and delete messages through this function.

Note: If the short message memory is full, a blinking message icon appears on the top of the screen.

Phonebook

The mobile phone can store up to 100 telephone numbers.

Calendar

Once you enter this menu, there is a monthly-view calendar for you to view.

Call History

Through this function, you can see the list of missed calls, dialed calls, received calls, all calls, delete records, call timer, message counter, GPRS counter.

Bluetooth

With Bluetooth, you can make a wireless connection to other compatible devices, such as mobile phones, computers, headsets and car kits. You can use the Bluetooth to send images, video clips, music, sound clips and notes, and transfer files from your compatible pc.

Web

Internet service

You can use Browser to view web pages and search for information on the web.

WAP

STK service is the tool kit of SIM card. This phone supports the service function. The specific items are depended by SIM card and network. Service menu will be auto added to the phone menu when supported

by network and SIM card.

Data account

This function enables you to set data account related parameters.

Games

A game named Magic Sushi is embedded in the phone. For specific operation, please refer to 'help' option of the game.

Image viewer

Pictures taken by camera can be scanned through this function.

Video player

You can use this function to play video files.

File manager

The phone provides a certain space for users to manage files and supports the T-Flash card. You can use the file manager to conveniently manage various directories and files on the phone and the T-Flash card.

Settings

Date and time

You can set time and date through this function.

Dual SIM switch

Manually selected by user and **automatically decided by SIM cards** are available for you to choose. You can select one of them as per your needs.

Dual SIM settings

Dual-SIM refers to two SIM card slots, and the two cards can standby at the same time or set one of them to display on the idle screen.

Pen calibration

Click anywhere on the screen with your style to start calibration. Then follow the prompt and operate, this operation allows the screen to respond more quickly and correctly.

Phone Settings

◆ **Time and date:** set the home city, time/date, format or update the time and date with time zone.

◆ **Schedule power on/off:** Set the time when the mobile phone will be automatically powered on or off.

Alert: Before entering an area where the use of mobile phones is forbidden, make sure that the scheduled power-on function is deactivated to avoid accidents.

◆ **Language:** Select the display language for the mobile phone.

◆ **Pref. input method:** Select an input method as preferred input method as per your need.

◆ **Flight mode:** when this function is engaged, it will suspend many of the device's signal transmitting functions – thereby disabling the device's capacity to place or receive calls or text messages– while still permitting use of other functions that do not require signal transmission (e.g., games, built-in camera, MP3 player.)

◆ **UART:** SIM1 and SIM2 are available for you to choose, you can select one of them as per your need.

Display Settings

Through this function, you can set the wallpaper, screen saver, turn on screen, off screen, display time and date, display operator name, owner number display, backlight.

Call settings

◆ **Caller ID:** You can select the ID set by the network, hide the ID, or send the ID. By default, the ID set by the network is chosen.

◆ **Call waiting:** Network dependent.

◆ **Call divert:** This network function enables you to forward incoming calls to another number you have previously specified.

◆ **Call barring:** The call barring function enables you to bar calls as needed. When setting this function, you need to use a network barring code, which can be obtained from the network operator.

◆ **Line switching:** Switch to Line 1 or Line 2. By default, Line 1 is used.

Note: If you choose Line 2, dialing may fail. This depends on the implementation of the network operator.

Common call settings

◆ **Blacklist:** He or she can't call you if you set the blacklist status to on and add his or her number to blacklist.

◆ **Auto redial:** Set it to **On** or **Off** to enable or disable auto redial. To end the auto redial process, press the **End** key.

◆ **Call time display:** Choose to display call time or not in a call.

- ◆ **Call time reminder:** To set single or periodic tone in a call to make you know the time.
- ◆ **Auto quick end:** This function enables you to end a call at a preset time.
- ◆ **Reject by SMS:** Reject an incoming call and reply the caller a short message to state that you are not available at this moment.
- ◆ **Connect notice:** Once this function is enabled, the phone would vibrate to remind you when a call is connected.
- ◆ **Answer mode:** Once select any key; you can press any key except the end key to answer an incoming call.

Network settings

Through this function, you can select network and set preferred network.

Security Settings

This function provides you with related settings about safety use.

Note: The initial phone lock code is 0000.

Restore Factory Settings

Use this function to restore factory settings.

Note: The initial password for restore factory settings is 0000.

Timer

The timer is a simple application for measuring time with possibility to register several results and suspend / resume measurement.

Chat

You will be able to log on to Facebook, MSN, Twitter and Yahoo through this feature.

User Profiles

The mobile phone contains multiple user profiles, including General, Silent, Meeting, Outdoor and my style.

Drive converter

Weight and length can be converted through this feature.

Currency Converter

Entering the range of foreign currency, may make the conversion between local and foreign currency....

Camera

Use this function to capture pictures.

Video recorder

This function enables you to record dynamic pictures.

Sound recorder

You can record AMR & WAV format audio files through this function.

FM radio

You need to insert earphone into its corresponding jack before using this function.

Audio player

Use this function to play audio files.

Alarm

Five alarm clocks are set but deactivated by default. You can activate one, multiple or all of them as needed.

World clock

Access this menu to view time of main cities in various time zones.

Tasks

This function enables you to create new memos.

Calculator

The calculator can add, subtract, multiply and divide.

FCC Regulations:

●This mobile phone complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

●This mobile phone has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

●The antenna(s) used for this transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

▶ **RF Exposure Information (SAR)**

This mobile phone meets the government's requirements for exposure to radio waves. This phone is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission of the U.S. Government.

The exposure standard for wireless mobile phones employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC is 1.6W/kg. *Tests for SAR are conducted using standard operating positions accepted by the FCC with the phone transmitting at its highest certified power level in all tested frequency bands. Although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value. This is because the phone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station antenna, the lower the power output.

The highest SAR value for the model phone as reported to the FCC when tested for use at the ear is 0.497 W/kg and when worn on the body, as described in this user guide, is 0.411 W/kg (Body-worn measurements differ among phone models, depending upon available accessories and FCC requirements.)

While there may be differences between the SAR levels of various phones and at various positions, they all meet the government requirement.

The FCC has granted an Equipment Authorization for this model phone with all reported SAR levels evaluated as in compliance with the FCC RF exposure guidelines. SAR information on this model phone is on file with the FCC and can be found under the Display Grant section of www.fcc.gov/oe/ea/fccid after searching on FCC ID: YHLBLUCHARLESTC.

For body worn operation, this phone has been tested and meets the FCC RF exposure guidelines for use with an accessory that contains no metal and the positions the handset a minimum of 1.5 cm from the body. Use of other accessories may not ensure compliance with FCC RF exposure guidelines. If you do not use a body-worn accessory and are not holding the phone at the ear, position the handset a minimum of 1.5 cm from your body when the phone is switched on.