Mode 9: IEEE 802.11ax 20 MHz Continuous TX mode_ANT-1	
5720 MHz	
5720 MHz	

Mode 9: IEEE 802.11ax 20 MHz Continuous TX mode_ANT-1	
5745 MHz	
5785 MHz	
5825 MHz	

Mode 9: IEEE 802.11ax 20 MHz Continuous TX mode_ANT-1	
5845 MHz	
5865 MHz	
5885 MHz	

Mode 10: IEEE 802.11ax 40 MHz Continuous TX mode_ANT-1	
5190 MHz	
5230 MHz	

Mode 10: IEEE 802.11ax 40 MHz Continuous TX mode_ANT-1	
5270 MHz	
5310 MHz	

Mode 10: IEEE 802.11ax 40 MHz Continuous TX mode_ANT-1	
5510 MHz	
5550 MHz	
5670 MHz	

Mode 10: IEEE 802.11ax 40 MHz Continuous TX mode_ANT-1	
5710 MHz	
5710 MHz	

Mode 10: IEEE 802.11ax 40 MHz Continuous TX mode_ANT-1	
5755 MHz	
5795 MHz	

Mode 10: IEEE 802.11ax 40 MHz Continuous TX mode_ANT-1	
5835 MHz	
5875 MHz	

Mode 11: IEEE 802.11ax 80 MHz Continuous TX mode_ANT-1	
5210 MHz	
5290 MHz	

Mode 11: IEEE 802.11ax 80 MHz Continuous TX mode_ANT-1	
5530 MHz	
5610 MHz	

Mode 11: IEEE 802.11ax 80 MHz Continuous TX mode_ANT-1	
5690 MHz	
5690 MHz	
5775 MHz	

Mode 11: IEEE 802.11ax 80 MHz Continuous TX mode_ANT-1	
5855 MHz	

Mode 12: IEEE 802.11ax 80 + 80 MHz Continuous TX mode_ANT-1	
5210 MHz	

Mode 12: IEEE 802.11ax 80 + 80 MHz Continuous TX mode_ANT-1	
5530 MHz	

Mode 12: IEEE 802.11ax 80 + 80 MHz Continuous TX mode_ANT-1	
5775 MHz	

Mode 2: IEEE 802.11a Continuous TX mode_ANT-2	
5180 MHz	
5200 MHz	
5240 MHz	

Mode 2: IEEE 802.11a Continuous TX mode_ANT-2	
5260 MHz	
5280 MHz	
5320 MHz	

Mode 2: IEEE 802.11a Continuous TX mode_ANT-2	
5500 MHz	
5560 MHz	
5700 MHz	

Mode 2: IEEE 802.11a Continuous TX mode_ANT-2	
5720 MHz	
5720 MHz	

Mode 2: IEEE 802.11a Continuous TX mode_ANT-2	
5745 MHz	
5785 MHz	
5825 MHz	

Mode 2: IEEE 802.11a Continuous TX mode_ANT-2	
5845 MHz	
5865 MHz	
5885 MHz	

Mode 9: IEEE 802.11ax 20 MHz Continuous TX mode_ANT-2	
5180 MHz	
5200 MHz	
5240 MHz	

Mode 9: IEEE 802.11ax 20 MHz Continuous TX mode_ANT-2	
5260 MHz	
5280 MHz	
5320 MHz	

Mode 9: IEEE 802.11ax 20 MHz Continuous TX mode_ANT-2	
5500 MHz	
5560 MHz	
5700 MHz	

Mode 9: IEEE 802.11ax 20 MHz Continuous TX mode_ANT-2	
5720 MHz	
5720 MHz	

Mode 9: IEEE 802.11ax 20 MHz Continuous TX mode_ANT-2	
5745 MHz	
5785 MHz	
5825 MHz	

Mode 9: IEEE 802.11ax 20 MHz Continuous TX mode_ANT-2	
5845 MHz	
5865 MHz	
5885 MHz	

Mode 10: IEEE 802.11ax 40 MHz Continuous TX mode_ANT-2	
5190 MHz	
5230 MHz	

Mode 10: IEEE 802.11ax 40 MHz Continuous TX mode_ANT-2	
5270 MHz	
5310 MHz	

Mode 10: IEEE 802.11ax 40 MHz Continuous TX mode_ANT-2	
5510 MHz	
5550 MHz	
5670 MHz	

Mode 10: IEEE 802.11ax 40 MHz Continuous TX mode_ANT-2	
5710 MHz	
5710 MHz	

Mode 10: IEEE 802.11ax 40 MHz Continuous TX mode_ANT-2	
5755 MHz	
5795 MHz	

Mode 10: IEEE 802.11ax 40 MHz Continuous TX mode_ANT-2	
5835 MHz	
5875 MHz	

Mode 11: IEEE 802.11ax 80 MHz Continuous TX mode_ANT-2	
5210 MHz	
5290 MHz	

Mode 11: IEEE 802.11ax 80 MHz Continuous TX mode_ANT-2	
5530 MHz	
5610 MHz	

Mode 11: IEEE 802.11ax 80 MHz Continuous TX mode_ANT-2	
5690 MHz	
5690 MHz	
5775 MHz	

Mode 11: IEEE 802.11ax 80 MHz Continuous TX mode_ANT-2	
5855 MHz	

Mode 12: IEEE 802.11ax 80 + 80 MHz Continuous TX mode_ANT-2	
5290 MHz	

Mode 12: IEEE 802.11ax 80 + 80 MHz Continuous TX mode_ANT-2	
5610 MHz	

Mode 12: IEEE 802.11ax 80 + 80 MHz Continuous TX mode_ANT-2	
5855 MHz	

Mode 2: IEEE 802.11a Continuous TX mode_ANT-3	
5180 MHz	
5200 MHz	
5240 MHz	

Mode 2: IEEE 802.11a Continuous TX mode_ANT-3	
5260 MHz	
5280 MHz	
5320 MHz	

Mode 2: IEEE 802.11a Continuous TX mode_ANT-3	
5500 MHz	
5560 MHz	
5700 MHz	

Mode 2: IEEE 802.11a Continuous TX mode_ANT-3	
5720 MHz	
5720 MHz	

Mode 2: IEEE 802.11a Continuous TX mode_ANT-3	
5745 MHz	
5785 MHz	
5825 MHz	

Mode 2: IEEE 802.11a Continuous TX mode_ANT-3	
5845 MHz	
5865 MHz	
5885 MHz	

Mode 9: IEEE 802.11ax 20 MHz Continuous TX mode_ANT-3	
5180 MHz	
5200 MHz	
5240 MHz	

Mode 9: IEEE 802.11ax 20 MHz Continuous TX mode_ANT-3	
5260 MHz	
5280 MHz	
5320 MHz	

Mode 9: IEEE 802.11ax 20 MHz Continuous TX mode_ANT-3	
5500 MHz	
5560 MHz	
5700 MHz	

Mode 9: IEEE 802.11ax 20 MHz Continuous TX mode_ANT-3	
5720 MHz	
5720 MHz	

Mode 9: IEEE 802.11ax 20 MHz Continuous TX mode_ANT-3	
5745 MHz	
5785 MHz	
5825 MHz	

Mode 9: IEEE 802.11ax 20 MHz Continuous TX mode_ANT-3	
5845 MHz	
5865 MHz	
5885 MHz	

Mode 10: IEEE 802.11ax 40 MHz Continuous TX mode_ANT-3	
5190 MHz	
5230 MHz	

Mode 10: IEEE 802.11ax 40 MHz Continuous TX mode_ANT-3	
5270 MHz	
5310 MHz	

Mode 10: IEEE 802.11ax 40 MHz Continuous TX mode_ANT-3	
5510 MHz	
5550 MHz	
5670 MHz	

Mode 10: IEEE 802.11ax 40 MHz Continuous TX mode_ANT-3	
5710 MHz	
5710 MHz	

Mode 10: IEEE 802.11ax 40 MHz Continuous TX mode_ANT-3	
5755 MHz	
5795 MHz	

Mode 10: IEEE 802.11ax 40 MHz Continuous TX mode_ANT-3	
5835 MHz	
5875 MHz	

Mode 11: IEEE 802.11ax 80 MHz Continuous TX mode_ANT-3	
5210 MHz	
5290 MHz	

Mode 11: IEEE 802.11ax 80 MHz Continuous TX mode_ANT-3	
5530 MHz	
5610 MHz	

Mode 11: IEEE 802.11ax 80 MHz Continuous TX mode_ANT-3	
5690 MHz	
5690 MHz	
5775 MHz	

Mode 11: IEEE 802.11ax 80 MHz Continuous TX mode_ANT-3	
5855 MHz	

Mode 12: IEEE 802.11ax 80 + 80 MHz Continuous TX mode_ANT-3	
5290 MHz	

Mode 12: IEEE 802.11ax 80 + 80 MHz Continuous TX mode_ANT-3	
5610 MHz	

Mode 12: IEEE 802.11ax 80 + 80 MHz Continuous TX mode_ANT-3	
5855 MHz	

---END---