



Quick Start Guide: R3

Quick Start Guide

ClamCase Pro

Quick Start Guide

ClamCase Pro

Quick Start Guide

Welcome!


Why ClamCase is awesome

"you bought the best iPad keyboard made. We are sure
you will love it blah blah"

Welcome!


These are the mode illustrations
to be used on these pages

Top 3-5
Features
(FPO)




Tablet Mode

Top 3-5
Features
(FPO)




Touchscreen Mode

N/A




1 | Setup

- Place your iPad inside the **bottom edge** of the ClamCase.
- Press your iPad into the **top edge** of the Clamcase and it will **snap in** securely.
- To remove, **snap back** the top clip of the ClamCase and **release** your iPad.




1 Setup




2 Charge

- Charge your ClamCase with the supplied **USB cable** until the charging indicator **LED** turns **green**.
- A full charge can take up to **120 min**.






2 Charge



3 | Power


- Turn on the ClamCase **keyboard** before use.
- (!) When in tablet mode, the keyboard automatically turns off to avoid unintentional key strokes.





4 Pairing

- When ClamCase is turned on it **automatically** goes into **pairing mode**.
- On your iPad open '**Settings**' and tap Bluetooth making sure **Bluetooth** is **turned on**.



ⓘ Manual Pairing: On your ClamCase keyboard press and hold the Function+Bluetooth key for 5 sec. The pairing LED will begin flashing.

ClamCase Keyboard Not Connected ⓘ

'ClamCase Keyboard' will appear on the screen. Tap 'ClamCase Keyboard' to **select device**.

ClamCase Keyboard Connected ⓘ



Your iPad and ClamCase are now paired.

ⓘ Pairing process differs on iOS 5 or earlier

4 Pairing





5 | Function Keys



(!) To access the function keys (shown here in blue) press and hold the 'fn' button, then press the key with the desired function.

Function Keys



!

blue



Troubleshooting

- Press **any key** to wake your ClamCase from **sleep mode**.
- Turn your ClamCase **off** and then back **on**.
- **Recharge** the ClamCase battery.
- **Re-establish** a Bluetooth **connection** between your ClamCase and iPad.
- Verify your **iPad's Bluetooth** feature is turned **on**.

Contact



customerservice@clamcase.com



800.939.0335



clamcase.com/support

Suggested Change

support@clamcase.com




800.939.0335

clamcase.com/support



Troubleshooting

Contact



FCC COMPLIANCE STATEMENT

The equipment has been tested and found to comply with limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur on a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To assure continued compliance, any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.
(Example - use only shielded interface cables when connecting computer or peripheral devices).

USA: This device complies with Part 15 of the FCC Rules. Operation is subject to the following conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Canada: Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

To satisfy RF exposure requirements, this device and its antenna must operate with a separation distance of at least 20 centimeters from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter.


Disposal and Recycling Information

When this product reached its end of life, please dispose of it according to your local environmental laws and guidelines.


Battery Disposal Information

Dispose of batteries according to your local environmental laws and guidelines.

No SpotUVs







fin