






IEEE 802.11ac_Channel 114_160MHz_Antenna 1




IEEE 802.11ax_Channel 36_20MHz_Antenna 1_RU&Index SU




IEEE 802.11ax_Channel 44_20MHz_Antenna 1_RU&Index SU




IEEE 802.11ax_Channel 48_20MHz_Antenna 1_RU&Index SU




IEEE 802.11ax_Channel 52_20MHz_Antenna 1_RU&Index SU




IEEE 802.11ax_Channel 60_20MHz_Antenna 1_RU&Index SU




IEEE 802.11ax_Channel 64_20MHz_Antenna 1_RU&Index SU




IEEE 802.11ax_Channel 100_20MHz_Antenna 1_RU&Index SU




IEEE 802.11ax_Channel 116_20MHz_Antenna 1_RU&Index SU




IEEE 802.11ax_Channel 140_20MHz_Antenna 1_RU&Index SU




IEEE 802.11ax_Channel 38_40MHz_Antenna 1_RU&Index SU




IEEE 802.11ax_Channel 46_40MHz_Antenna 1_RU&Index SU




IEEE 802.11ax_Channel 54_40MHz_Antenna 1_RU&Index SU




IEEE 802.11ax_Channel 62_40MHz_Antenna 1_RU&Index SU




IEEE 802.11ax_Channel 102_40MHz_Antenna 1_RU&Index SU



IEEE 802.11ax_Channel 110_40MHz_Antenna 1_RU&Index SU



IEEE 802.11ax_Channel 134_40MHz_Antenna 1_RU&Index SU



IEEE 802.11ax_Channel 42_80MHz_Antenna 1_RU&Index SU

Shenzhen UnionTrust Quality and Technology Co., Ltd.

Address: Unit D/E of 9/F and 16/F, Block A, Building 6, Baoneng science and technology park, Longhua district, Shenzhen, China


Tel: +86-755-28230888

Fax: +86-755-28230886


E-mail: info@uttlab.com

<http://www.uttlab.com>


UTTR-RF-FCCPART15.407-V1.3




IEEE 802.11ax_Channel 58_80MHz_Antenna 1_RU&Index SU




IEEE 802.11ax_Channel 106_80MHz_Antenna 1_RU&Index SU




IEEE 802.11ax_Channel 50_160MHz_Antenna 1_RU&Index SU




IEEE 802.11ax_Channel 114_160MHz_Antenna 1_RU&Index SU



IEEE 802.11a_Channel 36_20MHz_Antenna 2



IEEE 802.11a_Channel 44_20MHz_Antenna 2



Shenzhen UnionTrust Quality and Technology Co., Ltd.

Address: Unit D/E of 9/F and 16/F, Block A, Building 6, Baoneng science and technology park, Longhua district, Shenzhen, China


Tel: +86-755-28230888

Fax: +86-755-28230886

E-mail: info@uttlab.com

<http://www.uttlab.com>

UTTR-RF-FCCPART15.407-V1.3



Shenzhen UnionTrust Quality and Technology Co., Ltd.

Address: Unit D/E of 9/F and 16/F, Block A, Building 6, Baoneng science and technology park, Longhua district, Shenzhen, China


Tel: +86-755-28230888

Fax: +86-755-28230886

E-mail: info@uttlab.com

<http://www.uttlab.com>

UTTR-RF-FCCPART15.407-V1.3



Shenzhen UnionTrust Quality and Technology Co., Ltd.

Address: Unit D/E of 9/F and 16/F, Block A, Building 6, Baoneng science and technology park, Longhua district, Shenzhen, China


Tel: +86-755-28230888

Fax: +86-755-28230886

E-mail: info@uttlab.com

<http://www.uttlab.com>

UTTR-RF-FCCPART15.407-V1.3



Shenzhen UnionTrust Quality and Technology Co., Ltd.

Address: Unit D/E of 9/F and 16/F, Block A, Building 6, Baoneng science and technology park, Longhua district, Shenzhen, China


Tel: +86-755-28230888

Fax: +86-755-28230886

E-mail: info@uttlab.com

<http://www.uttlab.com>

UTTR-RF-FCCPART15.407-V1.3



Shenzhen UnionTrust Quality and Technology Co., Ltd.

Address: Unit D/E of 9/F and 16/F, Block A, Building 6, Baoneng science and technology park, Longhua district, Shenzhen, China


Tel: +86-755-28230888

Fax: +86-755-28230886

E-mail: info@uttlab.com

<http://www.uttlab.com>

UTTR-RF-FCCPART15.407-V1.3



Shenzhen UnionTrust Quality and Technology Co., Ltd.

Address: Unit D/E of 9/F and 16/F, Block A, Building 6, Baoneng science and technology park, Longhua district, Shenzhen, China


Tel: +86-755-28230888

Fax: +86-755-28230886

E-mail: info@uttlab.com

<http://www.uttlab.com>

UTTR-RF-FCCPART15.407-V1.3



Shenzhen UnionTrust Quality and Technology Co., Ltd.

Address: Unit D/E of 9/F and 16/F, Block A, Building 6, Baoneng science and technology park, Longhua district, Shenzhen, China



Tel: +86-755-28230888

Fax: +86-755-28230886


E-mail: info@uttlab.com

<http://www.uttlab.com>


UTTR-RF-FCCPART15.407-V1.3




IEEE 802.11ac_Channel 50_160MHz_Antenna 2




IEEE 802.11ac_Channel 114_160MHz_Antenna 2




IEEE 802.11ax_Channel 36_20MHz_Antenna 2_RU&Index SU




IEEE 802.11ax_Channel 44_20MHz_Antenna 2_RU&Index SU




IEEE 802.11ax_Channel 48_20MHz_Antenna 2_RU&Index SU




IEEE 802.11ax_Channel 52_20MHz_Antenna 2_RU&Index SU




IEEE 802.11ax_Channel 60_20MHz_Antenna 2_RU&Index SU




IEEE 802.11ax_Channel 64_20MHz_Antenna 2_RU&Index SU




IEEE 802.11ax_Channel 100_20MHz_Antenna 2_RU&Index SU




IEEE 802.11ax_Channel 116_20MHz_Antenna 2_RU&Index SU



IEEE 802.11ax_Channel 140_20MHz_Antenna 2_RU&Index SU




IEEE 802.11ax_Channel 38_40MHz_Antenna 2_RU&Index SU




IEEE 802.11ax_Channel 46_40MHz_Antenna 2_RU&Index SU




IEEE 802.11ax_Channel 54_40MHz_Antenna 2_RU&Index SU



IEEE 802.11ax_Channel 62_40MHz_Antenna 2_RU&Index SU



IEEE 802.11ax_Channel 102_40MHz_Antenna 2_RU&Index SU



IEEE 802.11ax_Channel 110_40MHz_Antenna 2_RU&Index SU