












<p>Quick Start Guide Smart Wireless Bullet Camera</p>  <p>Model: E97V</p>	<p>Welcome Thank you for choosing our smart camera. Getting started is easy.</p> <p>What's included</p> 	<p>Product Details</p>  <p>1. Connection Preparation Bring the camera and phone within 1 to 3 feet (30 to 100 centimeters) of the router.</p> <p>2. Get the APP and Account For the best experience, please download the "Tuya Smart" APP to your smartphone from App Store or Google Play or you can also scan the QR code below, the APP icon will be displayed after installed successfully.</p>	<p>3. Insert the Micro SD card</p> <p>● Pull out the rubber plug at the back of the camera.</p> 
---	--	---	--

<p>● Insert the right SD card to the slot gently and restore the cover for waterproof.</p>  <p>4. Connect the power to the camera Connect the power to the camera by DC12V/1A Power Adapter.</p> 	<p>5. Set up your camera</p> <ul style="list-style-type: none"> ● Press the Reset button for above 5 seconds, then release the button to start Reset processing. ● Launch the app from your smartphone and click the Sign Up button. Follow the on-screen instructions. ● Click "Add Device" or "+" on the right corner to add device. Then click "SecuritySensor" to select "Smart Camera". ● Click the button to confirm if the indicator is red and blinking quickly. When the correct working will be presented to proceed. ● Point the QR code to the camera lens for 15-20cm. When the indicator turns to blue and blink quickly, click to next step. If failed, please reset and go back to start again! 	<p>6. Place or Mount Your Camera</p>  <p>You can place your camera on a shelf or other flat surface, or you can mount it to the wall.</p> <p>To mount your camera to the wall:</p> <ul style="list-style-type: none"> • Fasten the mounting screw into the wall, and then mount the camera from the scene. • If you're mounting the camera to drywall, be sure the plastic drywall anchors that are provided. 	 <p>Mounting on Wall</p>  <p>Mounting on Ceiling</p>	<p>You're done! Congratulations! Your camera is set up and ready to go.</p>  <p>CE RoHS</p> <p>All trademarks are used for reference purposes only. Thanks again for choosing our smart camera! Make life safe in your house! Boost security mobility in your smartphone!</p>
--	--	--	--	---

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.