


AUSDOM®

User Manual




Airkey84


Low-profile Mechanical keyboard

Thank you for purchasing AUSDOM Low-profile Mechanical keyboard

Product Overview



Windows User can find corresponding keycaps from the package and replace them according to the schematic diagram.



Power Button
USB-C Port (For charging and wired connection)

2.4G USB Receiver
1. Make sure keyboard power button switch to "ON"
2. Take out your 2.4G USB receiver
3. Plug the receiver inside computer, and press **fn + 2.4G**, then you will connect with computer under 2.4G.


CN-1

Packing List

- 1* Low-profile Mechanical Keyboard
- 1* USB-C Charging Cable
- 1* User Manual
- 3* Keycaps for Windows


BT Connection Mode

- Turn the power button to ON, press and hold **fn + BT** keycaps for 3-5 seconds, then the keyboard turns to "pairing" mode and the keys' backlight indicator flashes rapidly.
- Turn on the device's "Bluetooth" function, search and select "AUSDOM Airkey84" for pairing.



2.4G USB Connection Mode

- Turn the power button to ON, press the **fn + 2.4G** once to switch to 2.4G USB connection mode.
- Plug the USB receiver into the device's USB port, it can plug and play.




CN-2

Wired Connection Mode

(Note: The keyboard is default wired connection mode when it powered off)

- Turn the power button to ON, press the **fn + ON/OFF** once to switch to wired connection mode.
- Plug the USB cable to the keyboard's USB C port and the computer's USB A port, it can support the wired connection function and also can charge the keyboard.



Note: in USB-C wired mode, the "ON/OFF" power switch has no function.

Change the Backlight Effects

- Press the **Light** once to change the backlight effects.
- Press and hold **Light** for 5 seconds to turn on/off the backlight effect.
- There are 14 kinds of lighting effects on keyboards.




CN-3

Switch the System

(Note: The keyboard is default compatible with Mac OS)

- Press **fn + Mac** once to switch to Mac OS.
- Press **fn + Win** once to switch to Windows System.



Note: The keyboard is default Mac system layout.

Multi-function and Multi-media Keys

Press **fn + M** once to select or switch Multi-function and Multi-media operation.




Multi-media function keys
F1 F2 F3 F4 F5 F6 F7 F8 F9 F10 F11 F12
Multi-function keys

CN-4

Sleep Mode

- The keyboard backlight would turn off automatically if no operation running more than 1 minute. It would turn to sleep mode when no operation running more than 30 minutes and the keyboard would disconnect with the device.
- Press any key to wake the keyboard up and it will be connected to the device automatically.




Note: The F1-F12 keys function is default multi-media control.

Charging the Keyboard

The GhostBar backlight would flash white when the keyboard is low battery, please charge it in time for working. And the backlight would be red in charging and it would be light off when fully charged.

Warm Tips: The keyboard may occur a little delay, stutters and unstable connections when in a low battery status.



CN-5

Specifications

| | | | |
|-----|-------------------------------|------------------------|--|
| ☀ | Decrease brightness | ☀ | Increase brightness |
| ☒☒ | Multi-windows display | ☒☒☒ | Switch application |
| ☒☒☒ | Decrease backlight brightness | ☒☒☒☒ | Increase backlight brightness |
| ⏮ | Previous track | ⏭ | Play/Pause |
| ⏭ | Next track | ⏸ | Mute |
| 🔊 | Volume down | 🔊 | Volume up |
| 🖨 | Print screen | fn + ctrl + del | Press and hold for 3 seconds to restore factory settings |

Note: Features and technical specifications are subject to change without notice, we apologize for any inconvenience.

Warranty

The Low-profile Mechanical Keyboard is covered by a 1-year manufacturer warranty. For more information, visit www.ausdom.com

Safety Instructions

⚠ Warning: Fire, electric shock, damage to keyboard device could occur if the following instructions are not obeyed


- ⚡ Danger (high risk) ⚠ Warning (Moderate risk) ⚠ Note (Poor risk)
- ✘ 1. Away from edge tool
- ✘ 2. Away from microwave radiation source
- ✘ 3. Do not place heavy objects on this product
- ✘ 4. No shocking and bending
- ⚠ 5. Away from oil, chemical, or organic solvents

CN-6

RECYCLING

This product bears the selective sorting symbol for Waste electrical and electronic equipment (WEEE). This means that this product must be handled pursuant to European directive 2012/19/EU in order to be recycled or dismantled to minimize its impact on the environment.

User has the choice to give his product to a competent recycling organization or to the retailer when he buys a new electrical or electronic equipment.



DC voltage

⎓ DC voltage

CN-7


Specifications

| | |
|--|------------------|
| Wireless Version | V5.0 |
| Pairing Name | AUSDOM Airkey84 |
| Wireless Range | 8m |
| Battery Capacity | 2000mAh |
| Continuous working time with backlight on | 20H |
| Continuous working time with backlight off | 787H |
| Standby Time | 365 Days |
| Charging Time | 2.5 H |
| Recharging Current | 800mA |
| Mechanical Axis | Low-profile Axis |

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.



CN-8

CAUTION

RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE
DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS


Note: Features and technical specifications are subject to change without notice, we apologize for any inconvenience.

Warranty

The Low-profile Mechanical Keyboard is covered by a 1-year manufacturer warranty. For more information, visit www.ausdom.com

Safety Instructions

- ⚠ Warning: Fire, electric shock, damage to keyboard device could occur if the following instructions are not obeyed
- ⚡ Danger (high risk) ⚠ Warning (Moderate risk) ⚠ Note (Poor risk)
- ✘ 1. Away from edge tool
- ✘ 2. Away from microwave radiation source
- ✘ 3. Do not place heavy objects on this product
- ✘ 4. No shocking and bending
- ⚠ 5. Away from oil, chemical, or organic solvents



DC voltage

⎓ DC voltage

CN-9

保修卡

保修期
产品自售出之日起7日内, 发生质量问题, 消费者可以选择退货、换货或修理。产品自售出之日起15日内, 发生质量问题, 消费者可选择换货或修理。本产品的品质保证期限以产品购买日起12个月内有效。

免费服务
在产品保修期内, 凡属产品本身质量引起的故障, 请用户凭此保修卡和购货凭证与经销商取得联系, 以享受免费保修。

以下情况恕不免费维修:
1. 无保修卡或损坏产品标签。
2. 自行拆解造成的损坏。
3. 因进水或跌落而造成的故障及人为机械损坏。
4. 因不可抗力造成的故障或损坏。

| | |
|--------|--|
| 客户姓名: | |
| 联系地址: | |
| 联系电话: | |
| 产品名称: | |
| 产品型号: | |
| 购买日期: | |
| 销售商: | |
| S/N 号: | |
| 维修记录: | |

WARRANTY CARD

ATTENTIONS:
-Please read the return procedures and warranty policy carefully on www.ausdom.com before sending items back to point-of-purchase.
-Please fill the card and send it to your reseller together with the product if your product's warranty is valid.

| | |
|-------------------|--|
| S.N: | |
| Date of Purchase: | |
| Product Model: | |
| RMA Number: | |
| Return Reason: | |
| Customer Name: | |
| TEL: | |
| E-mail: | |
| Address: | |

WARRANTY CARD

ATTENTIONS:
-Please read the return procedures and warranty policy carefully on www.ausdom.com before sending items back to point-of-purchase.
-Please fill the card and send it to your reseller together with the product if your product's warranty is valid.

| | |
|-------------------|--|
| S.N: | |
| Date of Purchase: | |
| Product Model: | |
| RMA Number: | |
| Return Reason: | |
| Customer Name: | |
| TEL: | |
| E-mail: | |
| Address: | |

For more information, please visit our official website www.ausdom.com
Your valuable comments and suggestions on improving AUSDOM products are welcome!

support@ausdom.com sales@ausdom.com
www.ausdom.com

