


OFF-ROAD EXPLORER

RADIO CONTROLLED VEHICLE

BATTERY INSTALLATION


- The vehicle requires 5 "AA" 1.5V batteries (not included). The controller requires one 9V battery (included). When changing batteries, adult supervision is required. Use alkaline batteries for the best performance.
- Carefully remove items from the package.
 - Locate the battery door on the bottom of the vehicle.
 - Pull the latch on the door to the left and lift up to access the battery compartment. Insert 5 "AA" batteries while observing the correct polarity (Fig. 1).
 - Replace the battery compartment door.
 - Slide the battery door on the back of the controller down to open.
 - Insert one 9V battery while observing the correct polarity (Fig. 2).
 - Replace the battery compartment door.
 - Switch both the vehicle and controller power switches to the "ON" position.
 - Adjust the steering alignment lever located on the bottom of the vehicle (between front wheels) if the vehicle does not run straight when moving forward.

NOTE: For best operation, use the vehicle on a hard surface.




SAFETY PRECAUTIONS

- Do not operate during thunderstorms or rain.
- Avoid water, sand and snow when operating your vehicle.
- Do not submerge vehicle or controller in water.
- Never operate your vehicle on the street or highway.
- Adult supervision is recommended when operating this vehicle.
- Remove all batteries when not in use to avoid accidental operation.
- Never operate your vehicle in a confined or crowded area, and do not use people or animals as obstacles.
- Do not run your vehicle into furniture, objects or hard surfaces, as this will cause damage to both the objects and the vehicle.
- Keep fingers, hair and loose clothing away from the tires, gears and motor while the vehicle is switched to "ON".
- Do not leave vehicle or controller near sources of heat or under direct sunlight for long periods of time.
- Do not leave vehicle or controller outside overnight. Dampness is harmful to interior components.



- ### BATTERY WARNING:
- Do not mix old and new batteries.
 - Do not mix alkaline, standard carbon zinc, or rechargeable (nickel cadmium) batteries.
 - Insert batteries using the correct polarity. Do not short-circuit the supply terminal.
 - Remove batteries when not in use. Recycle or dispose of exhausted batteries, according to federal, state, and local laws. Do not dispose of batteries in a fire—they may leak or explode.
 - Use only manufacturer specified batteries (size, type) and/or adjusters, if applicable, specified by the manufacturer.
 - Always use, handle, and dispose of (rechargeable) batteries under adult supervision.
- KEEP THIS PACKAGE FOR REFERENCE AS IT CONTAINS IMPORTANT INFORMATION.



NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

©2018 MercoSource, LLC. Blue Hat Toy Company. Blue Hat Toy Company logos are trademarks of MercoSource, LLC. All rights reserved. Distributed by MercoSource, LLC, White, CA 92086. PREVENT PIRACY!

For technical support, please visit www.mercoamericans.com or call 1-800-274-2744. The artwork and design of this package are protected by US copyright law and may not be reproduced, distributed, displayed, published or used for any purpose without prior written permission. It is not permitted to alter, remove or reproduce any trademarks or copyright icons from this package.

2905105 (2301238)

6 94202 31814 0

Made in China

OFF-ROAD EXPLORER

RADIO CONTROLLED VEHICLE

TWO FREQUENCIES FOR COMPETITIVE RACING

BLUE HAT

AVAILABLE IN 2 FREQUENCIES!

9V BATTERY REQUIREMENT:
27 MHz
49 MHz

SPRING-LOADED SHOCKS FOR OFF-ROAD ACTION!

OFF-ROAD EXPLORER

RADIO CONTROLLED VEHICLE



SPRING-LOADED SHOCKS FOR OFF-ROAD ACTION!

WIRELESS RC ACTION!

BATTERY OPERATED PLAY VEHICLE AGES 6 AND UP

WARNING!
CHOKING HAZARD - Small parts. Not for children under 3 years.

AGES 6+

- ### EXCITING 4-WHEELING ACTION!
- LED Lights On Front End, Top And Rear For Night Driving
 - Knobby Tires For Rugged All-Terrain Performance
 - Spring-loaded Shocks For Hard Jumps And Turns
 - Available in 2 Frequencies for Competitive Racing

TWO FREQUENCIES FOR OFF-ROAD ACTION!

BLUE HAT

OFF-ROAD EXPLORER

RADIO CONTROLLED VEHICLE



- LED Lights On Front End, Top And Rear For Night Driving
- Knobby Tires for Rugged All-Terrain Performance
- Spring-loaded Shocks For Hard Jumps And Turns
- Available in 2 Frequencies for Competitive Racing

EXTRA-BRIGHT LED LIGHTS FOR RACING AT NIGHT!



SPRING-LOADED SHOCKS FOR OFF-ROAD ACTION!

WIRELESS RC ACTION!

FULL FUNCTION REMOTE CONTROL

BLUE HAT TOY COMPANY

SEE BOTTOM PANEL FOR COMPLETE OPERATING INSTRUCTIONS. KEEP THIS PACKAGE FOR REFERENCE AS IT CONTAINS IMPORTANT INFORMATION. Requires one "AA" (1.5V) battery (not included) and one "9V" battery (included).