封面 正面



MP230 Portable Bluetooth speaker


www.edifier.com

### ■ Important safety instruction

- Please read the instructions carefully. Keep it in safe place for future
- Use only accessories approved by the manufacturer.
- · Install the instrument properly by following the instructions in the device
- Using the product in a 0-35°C environment is recommended. Shipping and storing the product in a 0-35°C environment is recommended. . To reduce the risk of fire and electric shock, do not expose the product to rain or moisture.
- Do not use this product near water. Do not immerge the product into any liquid or have it exposed to dripping or splashing.
- . Do not install or use this product near any heat source (e.g. radiator, heater, stove, or other devices that generate heat).
- Do not place any object filled with liquids, such as vases on the product; neither should any open fire, such as lighted candles be placed on the product
- Do not block any ventilation openings. Do not insert any object into
- ventilation openings or slots. It may cause fire or electric shock · Keep sufficient clearance around the product to maintain good ventilation
- Do not force a plug into the jack. Before connection, check for blockage in the jack and whether the plug matches the jack and is criented to the right direction.
- · Keep the provided accessories and parts (such as screws) away from children to prevent from being swallowed by mistake.
- Do not open or remove the housing yourself. It may expose you to dangerous voltage or other hazardous risks. Regardless the cause of damage (such as damaged wire or plug, exposure to liquid splash or foreign object falling in, exposure to rain or moisture, product not working
- or being dropped, etc.), the repair has to be performed by an authorized service professional immediately. Before cleaning the product with dry cloth, always turn off the product and disconnect the nower plug first
- Never use strong acid, alkali, gasoline, alcohol, or other chemical solvents to clean the product surface. Use only neutral solvent or clear water for
- The product must be used at an altitude of lower than 2000m



Excessively loud music may lead to hearing loss. Please keep the



responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection

### For wireless product:

- Wireless product may generate shortwave radio frequencies and interfere with the normal use of other electronic devices or medical equipment.
- Turn off the product when it's disallowed. Do not use the product in. medical facilities, on airplane, at gas stations, near automatic gates, automatic fire alarm system or other automated devices.
- Do not use the product in the vicinity of a pacemaker within a 20cm range The radio waves may affect the normal operation of the pacemaker or other medical devices.



Battery powered products:

Danger of explosion if the battery is incorrectly replaced. Replace only with

same or equivalent type. Never disassemble, hit with force, squeeze

dispose of batteries in fire. Do not expose batteries in conductive materials liquid, fire or heat. Do not let metal object contact two battery poles. If the battery looks swollen, leaking, discolored, having odor or any abnormal appearance, stop using it. Do not use the battery after immersed in water. Improper use of battery may lead to explosion or leakage, causing skin burn or other injuries, in the event of battery leakage, handle it with care and immediately dispose of the battery in the manner in compliance with applicable laws and regulations in your locality.

### ■ What's in the Box









## ■ Specifications

Power output: 10W+10W Frequency response: 70Hz-13KHz Rated input: 5V === 2A

 Images are for illustrative purposes only and may differ from the actual product. · For the need of technical improvement and system upgrade, information and pecifications contained herein may be slightly different from actual approduct. If any difference is found, the actual product prevails.

## 封底



Manual Edition 1.0, July 2021














Press: volume up

■ Functional operation

Press: volume down

Press and hold: previous track



# Operating instructions

### Charge

- You may hear a warning tone when the speaker is at the low battery level, please charge it in time;
- Using a DC adapter (5V == 2A) to charge the speaker is ecommended;
- Red light steady lit = charging red light off = fully charged
- To extend service life of its batteries, please charge the speaker. every three months when it is not used for long periods of time.



### Bluetooth connection and playback

- It is Bluetooth connecting mode by default when the speaker is powered on for the first time, you can pair the speaker with Bluetooth devices (mobile phones, tablets, etc.).
- . The speaker is ready for Bluetooth connection when the blue light flashes rapidly, set your Bluetooth devices to search for and connect to "EDIFIER MP230".
- · Bluetooth on the speaker has been hidden when the blue light flashes slowly, you cannot discover "EDIFIER MP230" on your Bluetooth devices, please press the " \$ " button, or restart the speaker to enter Bluetooth connecting state.



# Operating instructions

### AUX connection and playback

- . Connect the speaker to a music player with the included audio
- Press the "♂ " button to switch to AUX mode (green light); then you can play music.

### microSD (TF) card mode playback

- . Insert a microSD (TF) card into the speaker;
- Press the " U " button to switch to microSD (TF) card mode (yellow light); then you can play music file in it

Note: Most files in MP3/WAV formart and some files in WMA/APE /FLAC can be played.

### USB audio streaming mode

- . Connect the speaker to a computer with the included USB cable; • Press the " U " button to switch to USB audio streaming mode (red light):
- . Open the computer's sound settings and select "EDIFIER MP230" as its output device: then it is ready for use.

### ■ Troubleshooting

- · Check if the speaker is ON
- Try to turn up the volume using the volume control.
- · Ensure the audio cables are firmly connected and the input is set correctly
- on the speaker.

  Check if there is a signal output from the audio source

### Cannot connect via Bluetooth

- Make sure the speaker is switched to Bluetooth input. If it is in other audio input modes, Bluetooth will not connect. Disconnect from any Bluetooth device by pressing and holding the " \* " button, then try again.
- · Effective Bluetooth transmission range is 10 meters; please ensure that operation is within that range.
- · Try another Bluetooth device for connection.

### The MP230 does not turn on

· Check if main power is connected, or if the wall outlet is switched on.

### Noise coming from speakers

· EDIFIER speakers generate little noise, while the background noise of some audio devices are too high. Please unplug audio cables and turn the volume up, if no sound can be heard at 1 meter away from the speaker,



Model: EDF100006

P.O. Box 6264 General Post Office

Tel: +852 2522 6989

Fax: +852 2522 1989 www.edifier.com

Hong Kong

Edifier International Limited

For the need of technical improvement and system upgrade, information contained herein may be subject to change from time to time without prior

© 2020 Edifier International Limited. All rights reserved.

Products of EDIFIER will be customized for different applications. Pictures and illustrations shown on this manual may be slightly different from actual product. If any difference is found, the actual product prevails.



# FCC Regulatory Compliance

Warning: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radic/TV technician for help.

# RF Exposure Compliance

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

# ISED Regulatory compliance

This device contains licence-exempt transmitters that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s).

Operation is subject to the following two conditions:

This device may not cause interference.

This device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

L'appareil ne doit pas produire de brouillage;

L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

This equipment complies with IC RSS-102 radiation exposure limits set forth for an uncontrolled environment.

Cet équipement est conforme aux limites d'exposition aux radiations IC CNR-102 établies pour un environnemert non contrôlé

IB-200-000000-14

	拱:	恭	V1. 2/1B-200-000000-14	V1. 2/ II	版本号及料号:	版本
	对:	校	125×120 (MM)	125×1.	4:	民
	版面设计:	版	纸	80g书纸	质:	\$
东莞市漫步者科技有限公司	及耳机	幸	说明书FCC ISED认证说明-便携式音箱及耳机		称:	佑

V1.1 改16警告语/V1.2 16改为1SED和更改部分文字说明