




RECEPTOR DE AUDIO INALÁMBRICO DE TRANSMISIÓN DE MÚSICA

## AP-BTM-1750IP



Yellow- (+12V) Constant power / Amarillo- (+12V) Potencia constante  
Blue - Remote Out / Azul - Salida remota  
+ Red- (+12V) Remote in/Switched Power / Rojo- (+12V) Entrada remota/12V conmutada)  
- Black- (-12V) Ground / Negra- (-12V) - Tierra  
White RCA - Left Output / RCA blanca - Salida Izquierda  
Red RCA - Right Output / RCA rojo - Salida derecha  
Aux in / Entrada auxiliar

### Wiring options:

Yellow ---- (+12V) Power  
Black ---- (-12V) Ground  
Red- (+12V) Remote in/Switched Power  
Blue ---- Remote Turn on (Output to Amp)  
RCA ---- (3.5mm) Audio output (Amp)  
Aux In ---- 3.5mm Audio input

### Unit installation

1. Connect Yellow (+12V) wire to constant power (battery)
2. Connect Black (-12V) wire to chassis ground
3. Connect RED to a switched 12V power source or the remote output of the head unit
4. Connect the Blue wire (remote out) to the amplifier
5. Connect RCA output to amplifier

### Pairing your device (required for operation):

1. Ensure your streaming device has wireless music stream enabled and that power is applied to the AP-BTM-1750IP. (The blue LED on the AP-BTM-1750IP will blink to indicate it is in pairing mode.)
2. Within your streaming device's wireless music stream setup menu, select "AP-BTM-1750IP" from the list of pairable devices.
3. When successfully connected, the Blue LED on the AP-BTM-1750IP will stop blinking and remain lit. A single beep will be heard through the connected audio system.

### Opciones de Cableado:

Amarillo ---- (+12V) Potencia  
Negra ---- (-12V) Tierra  
Rojo- (+12V) Entrada remota/12V conmutada)  
Azul ---- Encendido Remoto (Salida a Amplificador)  
RCA ---- (3.5mm) Salida de Audio (Amplificador)  
Entrada auxiliar ---- Entrada de audio de 3.5 mm

### Instalación de la Unidad

1. Conecte el cable amarillo (+12V) a la energía constante (Batería)
2. Conecte el cable negro (-12V) a la tierra del chasis
3. Conecte RED a una fuente de alimentación conmutada de 12V o a la salida remota de la unidad principal
4. Conecte el cable Azul (Salida Remota) al Amplificador
5. Conecte la salida RCA al Amplificador.

### Emparejar su dispositivo (requerido para la operación):

1. Asegúrese de que su dispositivo de transmisión tenga transmisión de música inalámbrica habilitada y que la energía se aplique al AP-BTM-1750IP. (El LED azul en el AP-BTM-1750IP parpadeará para indicar que está en modo de emparejamiento).
2. Dentro del menú de configuración de transmisión de música inalámbrica de su dispositivo de transmisión, seleccione "AP-BTM-1750IP" de la lista de dispositivos compatibles.
3. Cuando se conecta correctamente, el LED azul en el AP-BTM-1750IP dejará de parpadear y permanecerá encendido. Se escuchará un solo pitido a través del sistema de audio conectado.



RECEPTOR DE AUDIO INALÁMBRICO DE TRANSMISIÓN DE MÚSICA

## AP-BTM-1750IP

### FCC compliance statement:

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- [1] this device may not cause harmful interference, and
- [2] this device must accept any interference received, including interference that may cause undesired operation.

This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

### Radiation Exposure Statement

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance of 20cm from your body.