



INSTRUCTIONS





This instructions work for any of these models (each sold separately)



1) BATTERIES INSTALLATION


Vehicle rechargeable battery 6V (included)



BATTERIES INFORMATION


- Non-rechargeable batteries are not to be recharged.
- Rechargeable batteries are to be removed from the product before being charged (if designed to be removable).
- Rechargeable batteries are only be charged under adult supervision (if designed to be removable).
- Do not mix alkaline, standard (carbon zinc), or rechargeable batteries.
- Do not mix old and new batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Batteries are to be inserted with the correct polarity.
- Exhausted batteries are to be removed from the product.
- The supply terminals are not to be short-circuited.
- Dispose of battery(ies) safely.
- Do not dispose of this product in a fire. The batteries inside may explode or leak.
- Use alkaline batteries only.

Transmitter 2 x "AA" batteries (included)



2) CHARGING THE VEHICLE

This vehicle is equipped with a Lithium-Ion battery that is recharged via USB.




1.- Plug the USB cable to any computer or USB outlet brick (not included).


A complete energy charge would take approximately 90 minutes.

An adult can help you with this step.

2.- Open the storage compartment and carefully plug the battery to the vehicle's attached cord (as shown) then return and secure storage lid before operating the vehicle.



Plug to the vehicle



Alignment wheel

ON/OFF switch

Plug for rechargeable battery

Vehicle bottom view

3.- Once you are done with that, you are READY TO RUN!

3) LET'S TAKE THE TRAILS!

To run your Polaris™ vehicle is very easy, just check the next image.

Turn ON the transmitter by moving the ON/OFF switch. The transmitter Syncs automatically with the vehicle



If the vehicle pulls left or right while driving straight ahead you must adjust the alignment wheel (located on bottom of the vehicle).

TROUBLE SHOOTING

Problem	Solution
Vehicle doesn't move or moves too slow	<ul style="list-style-type: none"> - If the vehicle doesn't move check the transmitter's batteries are placed with the correct polarity. - Check the vehicle or transmitter ON/OFF switch is in ON position. - Maybe it's time to recharge your vehicle or change transmitter batteries.
The vehicle moves by itself or erratically	<ul style="list-style-type: none"> - Make sure there's no outside radio interference, keep as far away as possible from radio towers, electrical lines, transmitter antennas or tall buildings.

Polaris and its vehicle body designs and names are registered trademarks of Polaris Industries Inc. used under license. Polaris designs, engineers, manufactures and markets snowmobiles, all terrain vehicles (ATV's), Victory motorcycles and the Polaris RZR XP 4 1000, Polaris MRZR - D4 and Polaris RANGER XP-1000 for recreational and utility use. Information about the complete line of Polaris products, apparel and vehicle accessories is available from authorized Polaris dealers or anytime from the Polaris homepage at www.polaris.com

IMPORTED AND DISTRIBUTED BY:
FOTORAMA USA
615 1/2 SECOND STREET
HUDSON, VT, 54016
(715) 386 6420
SALES@FOTORAMAUSA.COM
MADE IN CHINA



Ready to Run



Full Function



Rechargeable Battery



USB Charger

6+ AGE

COLORS MAY VARY FROM THOSE SHOWN

ADULT SUPERVISION IS SUGGESTED

ITEM No: 3082/ 3083/ 3084

3083-US-2019B

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and**
- (2) this device must accept any interference received, including interference that may cause undesired operation.**