

WiFi

REPEATER

Mobile phone setup


2.4G / 5G

1

Plug in your wifi extender

After poweron, you will find the LED light will become from **Green** to **Blue** color. Then you can start to set up.

Abnormal:
Press "reset" hole on the bottom of the product for 8s with paperclip, or contact seller



2

Connect your extender SSID

Both 2.4G and 5G are available, choose 5G to setting


***NOTE:**
You can not surf the Internet until you finish all the setting steps, pls continue.



3

Sign in to management page
(Google Chrome&Mozilla Firefox recommended)

***NOTE:**
Pls make sure that you have connected the SSID(wifi-5g-xxxx) of the wifi extender successfully, most of the PC/smart will recognize and Sign in to the management page automatically. If not, pls enter **192.168.188.1** on the new browser.




4

Enter the default password:admin



5


Scan and select your host router SSID



6

Enter the password of your host router

***NOTE:**
Pls make sure of the right password (special characters not allowed, like "%")



7

Set your Extender SSID and password

Default SSID:
original SSID+Pro+2.4G/5G can be changed

Default router password:
abc12321



8

Check details and make a note of the Wireless Info

***NOTE:**
After check, click "Start Connect" and wait 30-60s



9

When you finished setting, pls wait 30-40s until extender light is on.

After the setting is completed, please observe the signal indicator. If it lights up, it means that the relay is successful. Please connect CSG-pro to the Internet! otherwise reconnect.

Please wait 34 seconds




10

The led light will become **Green/Red** color when you set Extender Mode successfully.

***NOTE:**

- Green color means greater signal
- Red color means weak signal
- Blue color means unsuccess



11

Reconnect your extender wifi



Reconnect the extender SSID, then get access to Internet

WiFi

REPEATER

PC setup step

2.4G / 5G

1

Plug In your wifi extender

After power on, you will find the LED light will become from **Green** to **Blue** color. Then you can start to set up.

Abnormal:
Press "reset" hole on the bottom of the product for 8s with paperclip, or contact seller




2

Connect your extender SSID

Both 2.4G and 5G are available, choose 5G to setting

***NOTE:**
You can not Surf the Internet until you finish all the setting steps, pls continue



3

Sign in to management page
(Google Chrome&Mozilla Firefox recommended)

***NOTE:**
Pls make sure that you have connected the SSID(wifi-5g-xxxx) of the wifi extender successfully, most of the PC/smart will recognize and Sign in to the management page automatically. If not, pls enter **192.168.188.1** on the new browser.



4

Enter the default password:admin



5

Scan and select your host router SSID

Both of Wireless of 2.4G and 5G can be extended, choose only one of the two each time.

Different Channels working together would interfere signal, and the network speed will get slow. Please change the main router channel in time.



6

Enter the password of your host router

***NOTE:**
Pls make sure of the right password (special characters not allowed, like "%")



7

Set your Extender SSID and password

Default SSID:
original SSID+Pro+2.4G/5G can be changed

Recommend:
Default router password, can be changed



8

Check details and make a note of the Wireless Info

***NOTE:**
After check, click "Start Connect" and wait 30-60s



9

When you finished setting, pls wait 30-40s until extender light is on.

After the setting is completed, please observe the signal indicator. If it lights up, it means that the relay is successful. Please connect CSG-pro to the Internet! otherwise reconnect.

Please wait 34 seconds



10

The led light will become **Green/Red** color when you set Extender Mode successfully.

***NOTE:**

- Green color means greater signal
- Red color means weak signal
- Blue color means unsuccess



11

Reconnect your extender wifi



Reconnect the extender SSID, then get access to Internet

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.

The use of the 5150 – 5250 MHz band is restricted to indoor use only. This restriction will be applied in all member states.