

## Phone Layout



1	Left soft key	9	Receiver
2	Navigation key	10	Camera
3	Dial/Answer key	11	Flash light
4	Right soft key	12	Earphone connector
5	Center key	13	SOS key
6	End key	14	Speaker
7	Keypad	15	USB connector
8	LCD Display		

### **Insert SIM card**

1. Power off the phone and remove other external power.
2. Take off the back cover and remove the battery of the phone.
3. Insert SIM card into the SIM card slot in the phone.

### **Remove and Install the battery**

The attached Li-ion battery along with the phone can be used after unpacking. For the first three times, please use up the power and charger it fully for new battery to perform well.

### **Install the battery**

1. Put the battery in the battery compartment, note that the metal end of the battery should be firstly inserted.
2. Put on the back cover.

### **Remove the Battery**

1. Take off the back cover.
2. Put finger on the side finger grip, and then lift up the battery from the finger grip to remove the battery.

## **Charging the battery**

Unplug the charger from the outlet and the phone when not in use. Do not leave a fully-charged handset connected to a charger because overcharging may shorten the lifetime of the battery. If unused, a fully charged battery will lose its charge over time. If the battery is completely discharged, the charging may not start immediately when you plug in the connector. Wait 10 to 15 minutes for the phone to begin charging. Use the battery only for its intended purpose. Never use any charger or battery that is damaged. Use only Bmobile Charger & Battery.

Note: The actual operation time of a battery varies based on the operation mode, network strength in different places and talk time.

## **Audio player**

The songs you store in the memory card will appear in the audio player. Please check if you have stored the songs in "My Music" folder. You should also check whether default storage is memory card.

## **Battery Saver**

For your battery long standby, you can enter menu-Battery Saver to enable the battery saver mode, this will make phone's ringtone volume and brightness low and torch will be off.

## **How to control volume**

When you call any number, music or watch the video you can control volume,press the up & down navigation key to adjust volume.

## **Restore factory settings**

Reset the phone to default values (factory settings). The phone password is required, which is "1234" by default.

## **Security settings**

When enter the security settings, you can set the phone lock function. The default passcode is "1234", you also can change the passcode by yourself. When set the phone lock on, restart the phone. This work. You have 3 chances to input the passcode. If chances finished, the phone will power off.

## **Privacy**

The Contacts/Call logs/Message/File manager/Camera/My files/Calendar/U Disk/Audio player/Video player, Set to open, every time need to enter the password into the corresponding function. to enter the main menu interface is set menu to input security code to enter.

## **Services**

To access this menu, enter the Main Menu in the standby mode and then select Internet. You can use the network-Related services with this function.

#### 15.19 Labeling requirements.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and(2) this device must accept any interference received, including interference that may cause undesired operation.

#### 15.21 Information to user.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

#### 15.105 Information to the user.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

#### Absorption Rate (SAR) information:

This mobile phone meets the government's requirements for exposure to radio waves. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons regardless of age or health. FCC RF Exposure Information and Statement The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. This device was tested for typical body-worn operations with the back of the handset kept 1.0cm from the body. To maintain compliance with FCC RF exposure requirements, use accessories that maintain a 1.0cm separation distance between the user's body and the back of the handset. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.

#### Body-worn Operation

This device was tested for typical body-worn operations. To comply with RF exposure requirements, a minimum separation distance of 1.0 cm must be maintained between the user's body and the handset,including the antenna. Third-party belt-clips, holsters, and similar accessories used by this device should not contain any metallic components. Body-worn accessories that do not meet these requirements may notcomply with RF exposure requirements and should be avoided. Use only the supplied or an approved antenna.