

## SAFETY & COMPLIANCE INFORMATION

Use Responsibly. Read all instructions and safety information before use.

 FAILURE TO FOLLOW THESE SAFETY INSTRUCTIONS COULD RESULT IN FIRE, ELECTRIC SHOCK, OR OTHER INJURY OR DAMAGE.

 BATTERY SAFETY

**Batteries:** Your CITIZEN Smart Clock requires batteries for use, batteries not included. Only use 1.5V alkaline or 1.2 NIMH rechargeable C-sized batteries. Never mix old and new batteries. Keep all of the batteries out of the reach of children. Do not open, disassemble, puncture, cut, bend, shred or heat the batteries and do not allow metal objects to touch the battery terminals on your CITIZEN Smart Clock as they can become hot and cause burns. Remove all batteries if they are worn out or before storing your CITIZEN Smart Clock for an extended period of time. Dispose of all batteries in accordance with applicable laws and regulations and do not dispose of batteries by throwing them into a fire. If any batteries begin to leak, take steps to prevent the fluid from coming into direct contact with skin or clothes as the fluid could be corrosive and may be toxic. Remove the batteries and clean the battery compartment in accordance with the battery manufacturer's recommendations.

**Other Safety Considerations:** Small parts contained in your device and its accessories may present a choking hazard to small children. Keep out of reach of children.

**Recycling CITIZEN Smart Clock:** In some areas, the disposal of certain electronic devices is regulated. Make sure you dispose of or recycle the CITIZEN Smart Clock in accordance with your local laws and regulations. For information about recycling, go to [www.citizenwatch.com](http://www.citizenwatch.com)

**Radio Frequency Exposure:** The output of the radio technology used in the CITIZEN Smart Clock is below the radio frequency exposure limits set by the Federal Communications Commission of the United States (FCC). Nevertheless, it is advised to use the device in such a manner that minimizes the potential for human contact during normal operation. This device should be installed and operated with at least 20 cm between the radiator and your body. Information on your device is on file with the FCC and can be found by inputting your device's FCC ID, which can be found on the base of the device, into the FCC ID Search form available at [www.fcc.gov/oet/ea/fccid](http://www.fcc.gov/oet/ea/fccid).

**Radio Frequency Information:** This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including any interference that may cause undesired operation. Note: This equipment has been tested and

found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

(i) Re-orient or relocate the receiving antenna.

(ii) Increase the separation between the equipment and receiver.

(iii) Connect the equipment into an electrical outlet on a circuit different from that to which the receiver is connected.

(iv) Consult the dealer or an experienced radio/TV technician for help. Changes or modifications to a product by the user that are not expressly approved by the party responsible for compliance could make the product no longer comply with the FCC Rules.

## For Canadian Consumers

### Innovation, Science and Economic Development Canada (ISED) Compliance

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions: (1) This device may not cause interference. (2) This device must accept any interference, including interference that may cause undesired operation of the device.

### Son fonctionnement est sujet aux deux conditions suivantes:

(1) le dispositif ne doit pas produire de brouillage préjudiciable, et  
(2) ce dispositif doit accepter tout brouillage reçu, y compris un brouillage susceptible de provoquer un fonctionnement indésirable.  
L'appareil doit être installé et utilisé avec une distance minimale de 20 cm entre le radiateur et votre corps.

**Information Regarding Exposure to Radio Frequency Energy:** This equipment complies with IC RSS-102 RF exposure limits set forth in an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20 cm between the radiator and your body.

**Servicing Your CITIZEN Smart Clock:** If your CITIZEN Smart Clock needs service, please contact Citizen Customer Service at [www.citizenwatch.com](http://www.citizenwatch.com).

## PRODUCT SPECIFICATIONS:

Model Number: CC5011  
Electrical Rating: 1.5VDC  
Power: 4x 1.5V C batteries  
Connectivity: BT BR, BLE 4.2  
Operating temperature: 0°C to 35°C  
Storage temperature: -10°C to 45°C

Maximum Radio Frequency Power:  
BT BR (2402-2480 MHz: 12dBm Max)  
BLE 4.2 (2402-2480 MHz: 9dBm Max)

## TERMS AND POLICIES

CITIZEN Smart Clock is an Alexa-compatible accessory. By using this device, you agree to be bound by the Amazon Privacy Notice, the Amazon Device Terms of Use, the Amazon Conditions of Use, and other terms and policies available at [www.citizenwatch.com](http://www.citizenwatch.com). CITIZEN Smart Clock is covered by a one-year Limited Warranty, detailed at [www.citizenwatch.com](http://www.citizenwatch.com)



© 2019 Citizen Watch Company of America, Inc. All rights reserved. Amazon, Alexa, Echo and all related logos and marks are trademarks of Amazon.com, Inc. or its affiliates. Made in China.

# CITIZEN


## smart clock

QUICK START GUIDE



## What's in the box

CITIZEN Smart Clock



## Set up your Citizen Smart Clock

### AUTO mode (Echo mode) instruction:


To pair your CITIZEN Smart Clock with a compatible Echo device:  
1. Pull the switch up (towards to the 12:00 position) inside the battery tray area so the device can be set in Auto mode (Echo mode).  
Note: If the batteries are already installed, remove at least 1 battery out first, then pull the switch up.



2. Insert batteries into your CITIZEN Smart Clock.  
3. Prior to mounting, place your CITIZEN Smart Clock within 9.1 meters of your compatible Echo device.  
4. Then say, "Alexa, set up my gadget" and follow the instructions.  
5. Press and hold the SET/PAIR button until the status LED is pulsing orange to put clock in setup mode.


## Set up your Citizen Smart Clock

### Manual mode (manual set time) instruction:



There are 3 buttons on the back of the movement.  
The left one is "Set/PAIR", middle one is "UP", the right one is "CALIBRATE"

1. Pull the switch down (towards to the 6:00 position) inside the battery tray area so the device can be set in manual mode.  
Note: If the batteries are already installed, remove at least 1 battery out first, then pull the switch down.











2. Power up the device, the clock hands will fast move to reset at 12:04. When the clock hands start to move at a normal pace, press and hold the "SET/PAIR" button for at least 3 seconds to enter manual set time mode.

Press "UP" button once, the minute hand will move by 1 minute.  
Long press "UP" button, the clock hands will fast move until you release the "UP" button.

Once the time is set, press "SET/PAIR" button to exit manual set time mode.

## Troubleshooting

STATUS COLOR	DESCRIPTION
	Pulsing orange In pairing mode
	Solid blue Paired
	Pulsing blue Time syncing or software updating
	Pulsing yellow Notification received
	Single blink red Battery is low
	Three blinks red An error occurred
	Three blinks blue Clock disconnected



## Maintaining your CITIZEN Smart Clock

Do not drop, throw, disassemble, crush, bend, puncture or paint your CITIZEN Smart Clock. If your CITIZEN Smart Clock gets wet, use rubber gloves to remove the batteries and wait for your CITIZEN Smart Clock to dry completely before installing new batteries. Do not attempt to dry your CITIZEN Smart Clock with an external heat source, such as a microwave oven or hair dryer. Clean your CITIZEN Smart Clock with a soft cloth and avoid using liquids or harsh chemicals that may damage your CITIZEN Smart Clock; be careful not to wipe your CITIZEN Smart Clock with anything abrasive.

Please retain the packaging information for future reference.

# CITIZEN

CITIZENWATCH.COM